

Water distribution
Heating and cooling

System Ekoplastik

Installation Manual



wavin

System Ekoplastik

Contents

Wavin Ekoplastik System	3
Utilisation of Wavin Ekoplastik System	3
Product Range Basic Information	4
Properties of Wavin Ekoplastik System	8
Operating parameters of Ekoplastik pipes	10
Calculating the pipeline's service life within the system	10
Ekoplastik Pipeline Routing Options	11
Manifolds – underfloor heating made of PP-RCT	12
Tables	16
Assembly Instructions	20
Material Transport and Storage	32
Pressure Test Certificate	33
Polyfusion Welding – Working Procedures	34
Welding With Electrofusion Sockets – Working Procedures	37
Repair of Damaged Piping	38
Additional Branching	39
Wavin Ekoplastik System diameters 160-250 mm.....	53
Technical information	54
Working the pipe	56
Tables	58



Wavin Ekoplastik System is produced in grey and green colour.

Utilisation of Wavin Ekoplastik System

The Ekoplastik piping system can be used for distribution systems in housing, administration and community buildings as well as for industrial and agricultural installations.

The system is designed for transport of cold and hot water as well as floor heating. In case of observance of the rules specified hereinafter the system is also suitable for central heating systems.

The Wavin Ekoplastik System can also be used for air distribution. It is possible to take further advantage of its chemical resistance and other system properties and use the system for transport of other liquids or gaseous or solid media; such usage, however, must not be done without a prior individual assessment. Chemical disinfection of hot water must not be performed without a prior assessment by the manufacturer. Permanent disinfection of hot water with chlorine dioxide shortens the service life of the system and therefore is not recommended.



Benefits

- ⌚ innovative technology
- ⌚ unique multilayer pipe reinforced with basalt fiber
- ⌚ all plastic pipe with PP-RCT
- ⌚ pipes and fittings in diameters 160-250 mm made from PP-RCT

(more information you can find in separate Catalogue for Wavin Ekoplastik System – Large diameters)

System Ekoplastik

Product Range Basic Information



Major areas of application of individual pipe types



Ekoplastik
PPR PN10
 \varnothing 20-125 mm

Ekoplastik
PPR PN16
 \varnothing 16-125 mm

Ekoplastik
PPR PN20
 \varnothing 16-125 mm

Ekoplastik
Evo / Evo Plus
 \varnothing 16-125 mm

Ekoplastik
Stabi Plus
 \varnothing 16-110 mm

Ekoplastik Fiber
Basalt Plus
 \varnothing 20-125 mm

Ekoplastik Fiber
Basalt Clima
 \varnothing 20-125 mm




max. 70 °C




max. 90 °C

Multilayer pipes made from PP-RCT




Ekoplastik Stabi Plus

- 3x lesser thermal expansion
- oxygen barrier
- heating



Ekoplastik Fiber Basalt Plus

- 3x lesser thermal expansion
- no need to shave before welding
- hot water, heating



Ekoplastik Fiber Basalt Clima

- 3x lesser thermal expansion
- no need to shave before welding
- cold water, air conditioning

System Ekoplastik

Product Range

Warranty

All standard elements of the Wavin Ekoplastik System are covered by a 10-year warranty period.

This guarantee is subject to a proper product application and adherence to this installation manual. Twenty-four months guarantee period is granted for other products.

There are separately mentioned standard elements for potable water and cold water and a separate standard element for cold water in the catalogue of products.

The warranty is only valid for installations consisting entirely of pipes and fittings from the Wavin Ekoplastik System. The warranty does not apply if the installation includes products from other manufacturers.

Product Range - Basic Information

Pipes and fittings of the Wavin Ekoplastik System are produced in the following sizes (external pipe diameter is shown): 16, 20, 25, 32, 40, 50, 63, 75, 90, 110 and 125 mm.

The pipes are produced in various combinations of operating pressure and temperatures in separate pressure lines (of various wall thicknesses):

All plastic pipe

S 5 (PN 10) for cold water and floor heating

S 3,2 (PN 16) for hot water and floor heating

S 2,5 (PN 20) for hot water and central heating

EVO Plus S 3,2 (16 mm), S 4 (32-125 mm), for cold and hot water, floor and central heating

Multilayer pipe

Ekoplastik Stabi Plus three-layer pipes with perforated aluminum foil (16-63mm, S 3,2) and STABI PLUS with perforated aluminum foil (75-110mm, S 4), for hot water and central heating

Ekoplastik Fiber Basalt Plus three-layer pipes S 3,2 (20-63 mm), S 4 (75-125 mm) reinforced with basalt fiber, for hot water and central heating

Ekoplastik Fiber Basalt Clima three-layer pipes S4 (20-32 mm), S5 (40-125 mm) reinforced with basalt fiber for cold water, air conditioning and cooling

Each class of application refers to a typical field of use and for a period of 50 years. Each class of application must be associated with the pressure it is designed for (operating system pressure). This information is assigned to each pipe in the following format: class of application/pressure, for example 1/10 bar. It means the pipe is categorized as class 1 and has the maximum operating pressure of 10 bar.

The classes of application according to ISO 10508:

⌚ **class 1** (supply of hot water of 60 °C, service life 50 years)

⌚ **class 2** (supply of hot water of 70 °C, service life 50 years)

⌚ **class 4** (floor heating, low temperature heaters, service life 50 years, assuming (in total for the entire lifetime) 2.5 years at the operating temperature of 20 °C, 20 years at the operating temperature of 40 °C, 25 years at the operating temperature of 60 °C, 2.5 years at the operating temperature of 70 °C)

⌚ **class 5** (high temperature heaters, service life 50 years, out of which (in total for the entire length of service life) 14 years at the operating temperature of 20 °C, 25 years at the operating temperature of 60 °C, 10 years at the operating temperature of 80 °C, 1 year at the operating temperature 90 °C). Maximum operating pressure (4, 6, 8, 10 bar) corresponding to the application class is calculated and assigned for each material and pipe series S.

The operating conditions of water distribution and heating are specified for four different classes of application (ISO 10508).

The Ekoplastik Stabi Plus pipes

are three-layer pipes: the inner wall of the pipe is made of polypropylene type 4 - PP-RCT and its wall thickness is identical to that of the pipe S 3,2 and S 4. During the course of production it is coupled to the layer of aluminium and subsequently covered with an outer layer of polypropylene. Due to the aluminium layer the pipe has an oxygen barrier and meets the requirements of DIN 4726 and CSN EN 21003 for oxygen permeability. The pipes have durability and thermal length expansion comparable to metal pipes. The PP-RCT pipes are labeled according to the wall thickness as the class „S“. In order to provide the aluminium foil with some mechanical protection the pipe is furnished with an external polypropylene layer. In some cases, vaporization of residual moisture from production of the internal polypropylene pipe may occur (in the form of bubbles and blisters under the external layer). However, as this external polypropylene layer does not affect the mechanical properties of the pipe, it is considered an aesthetical issue only.

The Ekoplastik Basalt Fiber Plus pipes

are three-layer pipes. The inner and outer layer is made of polypropylene type 4 (PP-RCT). The middle layer is from polypropylene type 4 (PP-RCT) reinforced with basalt fibers (BF). The composition of the layers can be schematically described as PP-RCT / PP-RCT + BF / PP-RCT. Due to the basalt fiber the thermal expansion occurring in the BASALT FIBER PLUS pipe is three times lower than in the all-plastic pipes.

For a detailed and updated list of components see our Product Catalogue.

Fittings

(and adaptors) are manufactured for all piping types in the highest PN 20 pressure range and in various configurations:

- ⌚ Full-plastic fittings (sockets, elbows, T-pieces reduced and full-sized, reducers, blindings, cross-pieces).
- ⌚ Combined fittings with brass, nickel-coated threads for threaded joints (reducing sleeves with metal thread, T-pieces, elbows for wall mounting, wall mounting groups with tap connectors, plastic reducing sleeves with cap nut)
- ⌚ Combined fittings for flanged joints
- ⌚ Plastic valves with brass throttle (classic and under-plaster types)
- ⌚ Ball valve with a chrome – plated mantle (classic and under-plaster types)
- ⌚ Special elements (crossovers, compensation pipes)

Equipment and accessories:

- ⌚ Tools (welding and cutting devices, scrapers, thermometers and assembly jig)
- ⌚ Fixing clips, metal sleeves, plastic and metal troughs and plugs.

System Ekoplastik

Properties of Wavin Ekoplastik System

Advantages

- ① Service life of more than 50 years (subject to proper utilisation)
- ② No health risks
- ③ No corrosion or encrustation
- ④ Flexibility, low weight, easy and clean installation
- ⑤ Low-noise level, low pressure losses due to friction
- ⑥ Environmentally friendly product (can be recycled or safely incinerated)



Wavin Ekoplastik System is certified in the following countries:

Belorussia, Bulgaria, Croatia, Czech Republic, Germany, Hungary, Italy, Japan, Poland, Romania, Russia, Slovakia, Slovenia, Spain and Ukraine.

Wavin Ekoplastik System Marking

Pipes and fittings are marked during the manufacturing process to enable future tracing. All elements are marked in the following way:

Pipes: WAVIN Ekoplastik, S and PN, size, wall thickness, manufacturing standard (EN ISO 15874 and specifications of use according to this standard, see an example on page 10), date of production and code of manufacturing line.

Fittings: Ekoplastik (abbreviations such as EK or EKO may be used), material PPR or PP-RCT and size. Separate fitting packages are fitted with package labels containing not only the element type marking but also the date of production and releasing inspector's identification.

Pipes are marked according to the terms of EN ISO 15874 by code S – series (PN – pressure class).

Relationship between older PN pressure class marking, S and SDR for PPR pipes is listed in the table.

S	5	4	3,2	2,5
SDR	11	9	7,4	6
PN	10	-	16	20

The table can not be used for the new material PP-RCT because the pipes made from this material have better operating parameters (pressure, temperature, service life) than PPR pipes. The possibility to identify each element in a system is an important instrument of quality control management as well as an evidence for potential settlements of guarantee claims.

Specification of raw material used in production

Fittings of Wavin Ekoplastik System in diameter 16-63 mm are manufactured from Type 3 polypropylene. Fittings in diameter 75-125 mm are manufactured from polypropylene Type 4, PP-RCT. All plastic pipes EVO, multilayer pipes FIBER BASALT PLUS, FIBER BASALT CLIMA and STABI PLUS are made from polypropylene of new generation - type 4, PP-RCT.

Product manufacturing and testing standards

Ekoplastik PPR System products are manufactured according to internal company standard PN 01 corresponding to EN ISO 15874 and German standards DIN 8077 and DIN 8078, DIN 16962, DIN 4726.

The internal company standards are continuously being updated with further specification guidelines taken from the newly introduced European (EN) System of Standards.

Selected characteristics of pipes

characteristics		units	PPR value
specific gravity	PPR, PP-RCT	g / cm ³	0,9
thermal expansion coefficient (elongation)	all plastic pipes	mm / m °C	0,12
	multilayer pipes		0,05
thermal conductivity coefficient	all types of pipes	W / m °C	0,24

In order to meet quality requirements specified in ISO 9001, the following activities are regularly controlled within the framework of specified procedures

Assumed Properties of Piping System Agent

Controlled:

- ⌚ characteristics of raw materials entering the manufacturing process;
- ⌚ intermediate product parameters at every production stage
- ⌚ manufacturing facilities;
- ⌚ parameters of measuring instruments;

Basic parameters of internal water distribution systems

The following table shows basic criteria of pressure class selection – i.e. pressure and temperature values – as they may be present in internal water distribution systems.

medium	max. operating pressure [bar]	max. operating temperature [°C]
cold water	10	to 20 °C *
PWH (potable water hot)	10	to 60 °C **

* For hygienic reasons, the maximum temperature for drinking water is specified as 20 ° C.

**To prevent scalding, maximum temperature of 57 ° C is always assumed at the mixing tap in PWH distribution systems. A short-term overheating to higher temperature levels (70 ° C) is expected for hygienic reasons (extermination of pathogenic mycobacteria and bacteria Legionella pneumophila).

Wavin Ekoplastik System can be used for all internal water distribution systems (i.e. cold drinking water, cold industrial water, hot water, circulation systems).

The plastic piping system is expected to have a 50 years service life under the condition that the material and piping have been selected correctly and the system properly installed. The pressure class depends on the hot water heating system and its proper regulation and should therefore be specified by the relevant project designer.

Basic parameters of heating systems

When assessing the suitability of Ekoplastik PPR System elements, the temperature t1 - the highest temperature in the whole system - should be used as the input value for calculation. The heating system designer will determine this value depending on the temperature level required at the entry, heat source parameters, and expansion vessel types. According to this value, the following heating system types are specified.

Recommended values for heating – Wavin Ekoplastik System

Temperature interval

70 / 50 °C	70 / 60 °C	75 / 65 °C	80 / 60 °C
------------	------------	------------	------------

For low-temperature applications

When installing plastic piping system behind a boiler or a water tank, we recommend to install 1,5 – 2 m of metal piping as protection against overheating the piping system.

System Ekoplastik

Operating parameters of Ekoplastik pipes

The operating parameters service life the maximum operating pressure, temperature and lifetime and the relationship between them. The operating parameters are based on the material strength isotherm (PPR or PP-RCT) which shows the dependence of the media temperature, service life of the pipe and pipe tension. For each individual types of pipes the tension values were converted to the operational pressures and processed in tabular form (page 10). Service life assessment can be performed by deducing the values from tables or by using isotherms (PPR or PP-RCT depending on the type of pipe).

In order to calculate service life, a value of life factored stress in the pipe wall should be determined according to the following formula

$$\sigma_v = \frac{p \cdot (D - s)}{2 \cdot s} \cdot k$$

indication	
σ_v	factored stress [MPa]
D	pipe external diameter [mm]
s	pipe wall thickness [mm]
p	maximum pressure [MPa]
k	safety factor [for heating systems 1.5]

For calculation purposes: 1 MPa = 10 bars

The determined value of the designed tension will be generated to the vertical line of the chart. See the intersection of this value (horizontal line) with the isotherm of maximum water temperature (oblique line). Lead the vertical line from the intersection vertically downward, perpendicular to the horizontal axis, where you can deduct the minimum service life of the pipeline under continuous operation.

Another suitable design option in plastic piping utilisation is a common horizontal system where a pipeline is laid in a groove or along building structure in a cover (providing mechanical protection, allowing for expansion problems if any should occur, and improved visual appearance). Piping system designs should be also assessed with regard to their service life.

The following data are necessary for such evaluation:

- maximum water temperature [°C]
- maximum operating pressure [MPa]
- external diameter of the pipe [mm]
- wall thickness of the pipe [mm]
- safety factor for heating systems
- annual length of the heating period (in months)

Calculating the pipeline's service life within the system

Input data

parameters	values
piping – selected type	PPR S 2,5 (PN 20)
max. operating water temperature annual length of the heating period	80 °C
max. operating pressure	0,22 MPa
yearly heating period	7 months
safety factor	1,5

Minimum service life of a piping in continuous heating operation (as shown in the graph on page 12 for 80 °C isotherm) would then be 216,000 hours, i.e. 25 years.

$$\sigma_v = \frac{0,22 \cdot (20 - 3,4)}{2 \cdot 3,4} \cdot 1,5 = 0,80 \text{ MPa}$$

The resulting expected service life corrected to the annual heating period would then be as follows:

$$25 \text{ years} \cdot \frac{12 \text{ months}}{7 \text{ months}} = 43 \text{ years}$$

Heating system modifications applied in respect to piping service life

If the result received in the above procedures is not satisfactory, then the following modifications should be applied:

1/ decrease maximum operating pressure – new calculations should be made for the relevant heating system and service life expectancy; the modification should considerably extend service life expectancy.

2/ decrease maximum operating water temperature – new design calculations should be made for the relevant heating system and service life expectancy; the modification should considerably extend service life expectancy.

Ekoplastik Pipeline Routing Options

Routing options for water supply & distribution piping and heating systems are identical (leaving aside specific properties of heating systems as discussed in Chapter V and VII). The major aspects are the requirements for piping protection, support and compensation of expansion.

It is recommended that pipes are installed inside building structures (such as: wall, floor or ceiling structures) or covered. Connections to radiators should be, for visual appearance reasons, made of metal pipes, e.g. a chromium-coated copper pipe.

If the pipes are not covered and/or concealed it is necessary to take into account the fact that visible bubbles and blisters may appear on the Stabi pipes.

Pipes can be laid:

- in wall chases
- in stack partitions
- inside floor/ceiling structures
- along walls (freely or inside covers)
- in installation shafts and channels
- outdoor piping applications should be considered
- depending on local conditions

Specific characteristic for underfloor heating

room (purpose)	max. surface floor temperature
living unit	26 °C
bathroom	30 °C
swimming pool surroundings	32 °C

Maximum surface temperatures of walk-on floor layers must comply with standards for floor heating systems installations. Low flow rate levels of heating water (approx. 0.3 m.s⁻¹) are designed for heat transfer in floor heating systems. Piping pressure is designed according to operating parameters of the whole heating system.

Temperature of heating water is determined by a calculation where room type, floor structure and estimated outdoor temperatures for the particular building are taken into account. Temperature and pressure levels are usually not higher than 45 °C, 0,3 MPa respectively. For these purposes Ekoplastik PPR S 5, S 4 or S 3,2 lines are normally used. Heating circuits are laid using pipes delivered in coils. The pipe coils are more suitable for this purpose as no joints are necessary within the floor structure. Heating pipes are laid in a spiral shape pattern. Pipe diameters and spacing distances can be calculated. It is also necessary to specify in the floor heating design the type of floor heating output control and ensure that the maximum floor surface temperature is not exceeded. In rooms where higher output is required and places where people usually do not stay for any extended period of time (under windows) the heating pipes are laid in a dense pattern. On the other hand, no pipes should be laid in rooms where furniture is to be placed permanently. There is 100 meter maximum length of a heating coil per one heating circuit.


Room sections with more heating circuits must be separated to allow for expansion (including walk-on layers). Floor structures must also be separated from walls.

Individual circuits start and end in a manifold. An air bleeding valve must be placed at the highest point of the whole system. To minimise running costs, floor coverings should be made of material of the lowest possible thermal resistance (tiled floor surfaces are usually the most suitable).

Piping position and spacing between pipe centres should be fixed in the course of installation works – pipes may be fixed to a metal network of thermal insulation system and locked into spacing channels or profiled thermal insulation system. The installation process should follow the same rules and instructions that apply for water distribution systems installation.

During the course of the laying process the pipe should be carefully reeled off to prevent twisting. The pipe is then step-by-step fixed to the backing. Special attention should be paid to fixing the pipe to metal backing grids and care should be taken not to damage the pipe. Minimum temperature suitable for installation is 15 °C.

Floor heating is one of the very pleasant and effective heating methods. In order to make full use of all the advantages it offers, the heating system must be carefully designed and other factors should be taken into consideration as typically, the floor heating system would be only one of several types of heating used in the particular building.




Manifolds

New! Underfloor heating made of PP-RCT


We present you a unique system of plastic manifold sets. Now it is possible to easily assemble individual modules in a comprehensive system series of manifold sets from the simplest to fully adjustable ones. Specially designed fittings for manifolds are made of polypropylene PP-RCT type 4. Pipes and fittings made of such polypropylene have much higher resistance to pressure at higher temperatures than products made of polypropylene PPR type 3.

System Benefits

- ⦿ Modular system
 - Various combinations of manifold sets from the simplest to fully adjustable ones
 - Number of circuits can be adapted according to installation requirements from 2 to 12
- ⦿ Easy installation
 - Various combinations of numbers of circuits, flowmeters and regulations
- ⦿ Polyfusion welded joints
 - Absolute joint tightness
- ⦿ Designed for Wavin Ekoplastik System pipes with 16 and 20 mm diameters



Example of manifold sets with five circuits




Manifold assembly supply set

- 1 Ball tap plastic
- 2 Elbow 90° internal/external 16 or 20 mm
- 3a Manifold 3 circuits 32/20 mm
- 3b Manifold with regulation 3 circuits 32/16 or 32/20
- 4 Flowmeter body 16 or 20 mm
- 5a Manifold 2 circuits 32/20 mm
- 5b Manifold with regulation 2 circuits 32/16 or 32/20
- 6 Socket with drain valve internal/external
- 7 Flowmeter
- 8 Blanking plug 32 mm
- 9 Pipes in diameter 16 and 20 mm

System Ekoplastik

Examples of manifold assemblies with five circuits



ALL-PLASTIC MANIFOLD


Manifold shut-off	✓
Separate vents shut-off	✗
Water flow control	✗
Current flow rate metering	✗
Thermostatic control option	✗

Used fittings in diameters Ø 16 mm

Manifold 2 circuits 32/16 mm
Manifold 3 circuits 32/16 mm
Ball tap plastic 32 mm
Elbow 90° internal / external 16 mm
Blanking plug 32 mm
Socket with drain valve 32 mm

Used fittings in diameters Ø 20 mm

Manifold 2 circuits 32/20 mm
Manifold 3 circuits 32/20 mm
Ball tap plastic 32 mm
Elbow 90° internal / external 20 mm
Blanking plug 32 mm
Socket with drain valve 32 mm



MANIFOLD WITH THERMOSTATIC REGULATION


Manifold shut-off	✓
Separate vents shut-off	✓
Water flow control	✗
Current flow rate metering	✗
Thermostatic control option	✓

Used fittings in diameters Ø 16 mm

Manifold 2 circuits 32/16 mm
Manifold 3 circuits 32/16 mm
Manifold with regulation 2 circuits 32/16 mm
Manifold with regulation 3 circuits 32/16 mm
Ball tap plastic 32 mm
Elbow 90° internal / external 16 mm
Blanking plug 32 mm
Socket with drain valve 32 mm

Used fittings in diameters Ø 20 mm

Manifold 2 circuits 32/20 mm
Manifold 3 circuits 32/20 mm
Manifold with regulation 2 circuits 32/20 mm
Manifold with regulation 3 circuits 32/20 mm
Ball tap plastic 32 mm
Elbow 90° internal / external 20 mm
Blanking plug 32 mm
Socket with drain valve 32 mm



MANIFOLD WITH FLOWMETERS


Manifold shut-off	✓
Separate vents shut-off	✗
Water flow control	✓
Current flow rate metering	✓
Thermostatic control option	✗

Used fittings in diameters Ø 16 mm

Manifold 2 circuits 32/16 mm, 32/20 mm
 Manifold 3 circuits 32/16 mm, 32/20 mm
 Flowmeter body 16 mm
 Flowmeter
 Ball tap plastic 32 mm
 Blanking plug 32 mm
 Socket with drain valve 32 mm

Used fittings in diameters Ø 20 mm

Manifold 2 circuits 32/20 mm
 Manifold 3 circuits 32/20 mm
 Flowmeter body 20 mm
 Flowmeter
 Ball tap plastic 32 mm
 Blanking plug 32 mm
 Socket with drain valve 32 mm



MANIFOLD WITH THERMOSTATIC REGULATION AND FLOWMETERS

Manifold shut-off	✓
Separate vents shut-off	✓
Water flow control	✓
Current flow rate metering	✓
Thermostatic control option	✓

Used fittings in diameters Ø 16 mm

Manifold 2 circuits 32/20 mm
 Manifold 3 circuits 32/20 mm
 Manifold with regulation 2 circuits 32/16 mm
 Manifold with regulation 3 circuits 32/16 mm
 Flowmeter body 16 mm
 Flowmeter
 Ball tap plastic 32 mm
 Blanking plug 32 mm
 Socket with drain valve 32 mm

Used fittings in diameters Ø 20 mm

Manifold 2 circuits 32/20 mm
 Manifold 3 circuits 32/20 mm
 Manifold with regulation 2 circuits 32/20 mm
 Manifold with regulation 3 circuits 32/20 mm
 Flowmeter body 20 mm
 Flowmeter
 Ball tap plastic 32 mm
 Blanking plug 32 mm
 Socket with drain valve 32 mm

System Ekoplastik


Tables

Operating parameters of PPR and PP-RCT piping systems (according to DIN 8077/2007)

TEMPERATURE [°C]	TIME IN OPERATION (YEARS)	PPR			PP-RCT		
		S5 (PN10)	S3,2 (PN 16)	S2,5 (PN 20)	FIBER BASALT PLUS, STABI PLUS, EVO , FIBER BASALT OXY	FIBER BASALT CLIMA	
		S 4	S 3,2	S 5	MAXIMUM ALLOWABLE PRESSURE (BAR)		
10	1	17,5	27,8	35,1	24,0	30,2	19,0
	5	16,5	26,2	33,0	23,2	29,3	18,4
	10	16,1	25,6	32,2	22,9	28,9	18,2
	25	15,6	24,7	31,1	22,5	28,4	17,9
	50	15,2	24,1	30,3	22,2	28,0	17,7
20	1	15,0	23,7	29,9	20,9	26,3	16,6
	5	14,1	22,3	28,1	20,2	25,4	16,0
	10	13,7	21,7	27,4	19,9	25,1	15,8
	25	13,2	21,0	26,4	19,6	24,6	15,5
	50	12,9	20,4	25,7	19,3	24,3	15,3
30	1	12,7	20,2	25,4	18,1	22,7	14,3
	5	11,9	18,9	23,8	17,4	22,0	13,9
	10	11,6	18,4	23,2	17,2	21,7	13,6
	25	11,2	17,7	22,3	16,9	21,2	13,4
	50	10,9	17,2	21,7	16,6	20,9	13,2
40	1	10,8	17,1	21,6	15,5	19,6	12,3
	5	10,1	16,0	20,2	15,0	18,9	11,9
	10	9,8	15,5	19,6	14,7	18,6	11,7
	25	9,4	15,0	18,8	14,4	18,2	11,5
	50	9,2	14,5	18,3	14,2	17,9	11,3
50	1	9,1	14,5	18,2	13,3	16,7	10,5
	5	8,5	13,5	17,0	12,8	16,1	10,1
	10	8,2	13,1	16,5	12,6	15,8	10,0
	25	7,9	12,6	15,9	12,3	15,5	9,7
	50	7,7	12,2	15,4	12,1	15,2	9,6
60	1	7,7	12,2	15,4	11,2	14,2	8,9
	5	7,1	11,3	14,3	10,8	13,6	8,6
	10	6,9	11,0	13,9	10,6	13,4	8,4
	25	6,6	10,5	13,3	10,4	13,1	8,2
	50	6,4	10,2	12,9	10,2	12,8	8,1
70	1	6,5	10,3	12,9	9,4	11,9	7,5
	5	6,0	9,5	12,0	9,1	11,4	7,2
	10	5,8	9,2	11,6	8,9	11,2	7,0
	25	5,0	8,0	10,0	8,7	10,9	6,9
	50	4,2	6,7	8,5	8,5	10,7	6,8
80	1	5,4	8,6	10,8	7,9	9,9	6,2
	5	4,8	7,6	9,6	7,5	9,5	6,0
	10	4,0	6,4	8,1	7,4	9,3	5,9
	25	3,2	5,1	6,5	7,2	9,1	5,7
95	1	3,8	6,1	7,6	5,9	7,4	4,7
	5	2,6	4,1	5,2	5,6	7,1	4,4
COLD WATER		x	x	x	x	x	x
HOT WATER			x	x	x	x	
AIR		x	x	x	x	x	x
HEATING				x	x	x	

SAFETY FACTOR 1,5

Isothermal lines for PPR mechanical strength




Termination of the isotherm indicates maximum service life even at lower tensions.
The isotherms depicted in the chart are not extended.

System Ekoplastik

Tables

Isothermal lines for PP-RCT mechanical strength



Termination of the isotherm indicates maximum service life even at lower tensions.
The isotherms depicted in the chart are not extended.

Operating conditions according to ISO 10508

- application classes

Each class has defined system operating parameters for the total usage period of 50 years. Time when distribution system is exposed to high temperatures (Tmax) and temperatures during functional failure of the system (Tmal) are also included. Pipes are assigned certain maximum operating pressure.

When more than one operating temperature applies for a particular class, the periods are summed - see Service Life Total. All pipes compliant with the conditions in the table are suitable for cold water distribution for the period of 50 years at 20 °C and the pressure of 10 bar.

Class	service life total (years)	time of operation years / hr	operating temperature T °C	typical use	PPR S 2,5 SDR 6 (PN 20)	PPR S 3,2 SDR 7,4 (PN 16)	PP-RCT S 3,2 SDR 7,4	PP-RCT S 4 SDR 9	PP-RCT S 5 SDR 11
					max. operating pressure (bar)				
1	50 years	49 years	60	hot water 60°C	10	8	10	8	6
		1 year	80						
	Tmal/service life by Tmal	100 hr	95						
2	50 years	49 years	70	hot water 70°C	8	6	10	8	6
		1 year	80						
	Tmal/service life by Tmal	100 hr	95						
4	50 years	2,5 years	20	floor heating low temperature radiators	10	10	10	8	6
		20 years	40						
		25 years	60						
		2,5 years	70						
	Tmal/service life by Tmal	100 hr	100						
5	50 years	14 years	20	high temperature radiators	6	x	8	6	x
		25 years	60						
		10 years	80						
		1 year	90						
	Tmal/service life by Tmal	100 hr	100						

Application classes and appropriate maximum operating pressures are listed in the description of each pipe.

Example: PP-RCT pipe – S 3,2:

Class 1/10 bar, 2/10 bar, 4/10 bar, 5/8 bar means that the pipe may be used:


- for distribution of hot water of 60 °C - operating pressure 10 bar, service life of 50 years (class 1/10)
- for distribution of hot water of 70 °C - operating pressure 10 bar, service life of 50 years (class 2/10)
- for underfloor heating and low temperature radiators - operating pressure 10 bar, service life of 50 years (class 4/10)
- for high temperature radiators - operating pressure 8 bar, service life of 50 years (class 5/8)

System Ekoplastik


Assembly Instructions

General


Only components not damaged or contaminated, either during storage or transport, may be used for installation works.




Components of plastic piping systems must be protected against damage during transport and installation.



At lower temperatures it is difficult to provide proper working conditions for high-quality pipe coupling.



never be cut directly into plastic components. Threads are sealed with a special PTFE tape or sealing compounds.




Pipeline cross-overs should be made with components designed explicitly for this purpose.





Brazing or soldering of metal fittings should not take place close to a joint between metal and plastic systems due to the potential hazard of heat transfer to the fitting.

Components must not be exposed to naked flames.



Pipe bending should be done at +15 °C. For pipes of diameter range 16 – 32 mm a minimum bending radius equals to eight diameters (D).

Plastic parts joining is done by polyfusion welding or by using electrofusion sockets and butt welding techniques. A high-quality homogeneous joint is the result. The welding process must follow proper procedures and must be performed with appropriate tools.




It is recommended to use plastic plugs for blanking elbows or wall mounting groups (plastic plugs are designated only for temporary use). Long term blanking requires using plugs with metal thread.

Threaded fittings must be used for screw-type joints. Threads should

Linear expansion and contraction

Temperature differences during installation and under service conditions (i.e. when a medium flows through the system at a different temperature than that during the course of installation) result in linear changes – expansion or contraction (Δl)



$$\Delta l = \alpha \cdot L \cdot \Delta t [mm]$$

Δl linear change [mm]

α thermal expansion coefficient
[mm/m °C] for all plastic pipes
design purposes $\alpha = 0,12$,
for multilayer pipes respectively
 $\alpha = 0,05$

L effective length (distance between
two neighbouring fixed points
in line) [m]

Δt installation and service temperature
difference [°C]

$$L_s = k \cdot \sqrt{(D \cdot \Delta l)} [mm]$$


L_s compensating length [mm]

k material constant, for PPR $k = 20$

D external diameter of the pipe [mm]

Δl linear change [mm]

Expansion U-bend



FP – fixed point

SP – sliding point

L – design pipe length

Δl – compensating length

L_s – linear change

L_k – bend width

$$L_k = 2 \cdot \Delta l + 150 [mm]$$


and also $L_k \geq 10 \cdot D$

If pipeline linear changes are not compensated in a suitable way, i.e. if the pipes cannot contract and expand, additional pressure and tensile stress accumulating in the pipes shortens their service life.

In polypropylene applications linear compensation is often achieved through the pipe material's flexibility. Pipe bends can also be used for these purposes. One suitable compensation technique is where the pipeline is deflected perpendicularly to the original route and a free compensating length (marked as L_s) is left at the normal line. The value of L_s compensating length depends on calculated route extension (shortening), pipe material and diameter.


The values of Δl linear change and L_s compensating length can also be taken from the graphs shown on pages 20-22.

Compensation pipe




Compensation pipe table


pipe diameter (mm)	distances of all fixed L-points (m)	
	multilayer pipes	all plastic pipes
16	24	8
20	27	9
25	30	10
32	36	12
40	42	14



Compensation through modified pipeline routing



Compensation through modified height of the pipeline.



Compensating U-bend

System Ekoplastik

Assembly Instructions

Calculation examples for Ekoplastik PPR piping

1) Data input:

parameter	symbol	value	unit
linear change	Δl	?	mm
thermal expansion coefficient	α	0,12	mm/m °C
pipe length	L	10	m
operating temperature inside the pipe	t_p	60	°C
temperature at installation	t_m	20	°C
difference between operating and installation temperature levels ($\Delta t = t_p - t_m$)	Δt	40	°C

Solution: $\Delta l = \alpha \cdot L \cdot \Delta t$ [mm]
 $\Delta l = 0,12 \cdot 10 \cdot 40 = 48 \text{ mm}$

2) Data input:

parameter	symbol	value	unit
compensating length	L_s	?	mm
PPR material constant	k	20	-
external pipe diameter	D	40	mm
linear change as calculated above	Δl	48	mm

Solution: $L_s = k \cdot \sqrt{(D \cdot \Delta l)}$ [mm]
 $L_s = 20 \cdot \sqrt{(40 \cdot 48)} = 876 \text{ mm}$

3) Data input:

parameter	symbol	value	unit
Compensating U-bend width?			
external pipe diameter	D	40	mm
linear change as calculated above	Δl	48	mm

Solution: $L_k = 2 \cdot \Delta l + 150$ [mm]
 $L_k = 2 \cdot 48 + 150 = 246 \text{ mm}$
 $L_k \geq 10 \cdot D$
 $246 \text{ mm} < 10 \cdot 40 \Rightarrow L_k = 400 \text{ mm}$

Pipe pre-stressing can be also used for the purposes of linear expansion compensation; the compensating length may be made shorter this way. The pre-stressing orientation is opposite to the expected linear change and its value equals to about one half.

4) Data input:


parameter	symbol	value	unit
compensating length at pre-stressing	L_{sp}	?	mm
PPR material constant	k	20	-
external pipe diameter	D	40	mm
linear change as calculated above	Δl	48	mm

Solution: $L_{sp} = k \cdot \sqrt{(D \cdot \Delta l)}$ [mm]
 $L_{sp} = 20 \cdot \sqrt{(40 \cdot 48)} = 620 \text{ mm}$

Compensating length L_s (L_{sp}) is understood as a length of pipe without any sustaining or suspending elements (on this length) obstructing expansion. The compensating length L_s (L_{sp}) should not exceed max. spacing distance between supporting elements corresponding to the pipe diameter and media temperature as shown in page 22.

Linear expansion of Ekoplastik - all plastic pipe

Example: L = 10 m, $\Delta t = 40^\circ\text{C}$



pipe length	temperature difference Δt							
	10 °C	20 °C	30 °C	40 °C	50 °C	60 °C	70 °C	80 °C
	linear change Δl [mm]							
1 m	1	2	4	5	6	7	8	10
2 m	2	5	7	10	12	14	17	19
3 m	4	7	11	14	18	22	25	29
4 m	5	10	14	19	24	29	34	38
5 m	6	12	18	24	30	36	42	48
6 m	7	14	22	29	36	43	50	58
7 m	8	17	25	34	42	50	59	67
8 m	10	19	29	38	48	58	67	77
9 m	11	22	32	43	54	65	76	86
10 m	12	24	36	48	60	72	84	96
15 m	18	36	54	72	90	108	126	144


Rounded to whole numbers.

System Ekoplastik

Assembly Instructions

Linear expansion Ekoplastik - multilayer pipes

Example: $L = 10\text{ m}$, $\Delta t = 40\text{ }^{\circ}\text{C}$




pipe length	temperature difference Δt							
	10 °C	20 °C	30 °C	40 °C	50 °C	60 °C	70 °C	80 °C
	linear change Δl [mm]							
1 m	1	1	2	2	3	3	4	4
2 m	1	2	3	4	5	6	7	8
3 m	2	3	5	6	8	9	11	12
4 m	2	4	6	8	10	12	14	16
5 m	3	5	8	10	13	15	18	20
6 m	3	6	9	12	15	18	21	24
7 m	4	7	11	14	18	21	25	28
8 m	4	8	12	16	20	24	28	32
9 m	5	9	14	18	23	27	32	36
10 m	5	10	15	20	25	30	35	40
15 m	8	15	23	30	38	45	53	60

Rounded to whole numbers.

Determination of Ls – compensating length

Example: D 63 mm; $\Delta t = 20$ mm



pipe diameter [mm]	ΔI – linear change [mm]													
	10	20	30	40	50	60	70	80	90	100	110	120	130	140
	Ls – compensating length [mm]													
16	0,25	0,36	0,44	0,51	0,57	0,62	0,67	0,72	0,76	0,80	0,84	0,88	0,91	0,95
20	0,28	0,40	0,49	0,57	0,63	0,69	0,75	0,80	0,85	0,89	0,94	0,98	1,02	1,06
25	0,32	0,45	0,55	0,63	0,71	0,77	0,84	0,89	0,95	1,00	1,05	1,10	1,14	1,18
32	0,36	0,51	0,62	0,72	0,80	0,88	0,95	1,01	1,07	1,13	1,17	1,24	1,29	1,34
40	0,40	0,57	0,69	0,80	0,89	0,98	1,06	1,13	1,20	1,26	1,33	1,39	1,44	1,5
50	0,45	0,63	0,77	0,89	1,00	1,10	1,18	1,26	1,34	1,41	1,48	1,55	1,61	1,67
63	0,50	0,71	0,87	1,00	1,12	1,23	1,33	1,42	1,50	1,59	1,66	1,74	1,81	1,88
75	0,55	0,77	0,95	1,10	1,22	1,34	1,45	1,55	1,64	1,73	1,82	1,90	1,97	2,05
90	0,60	0,85	1,04	1,20	1,34	1,47	1,59	1,70	1,80	1,90	1,99	2,08	2,16	2,24
110	0,66	0,94	1,15	1,33	1,48	1,62	1,75	1,88	1,99	2,10	2,20	2,30	2,39	2,48
125	0,71	1,00	1,22	1,41	1,58	1,73	1,87	2,00	2,12	2,24	2,35	2,45	2,55	2,65

Rounded to whole numbers.

System Ekoplastik

Assembly Instructions

Spacing distance between pipe supports

Maximum pipeline supports spacing of Ekoplastik **PPR S 5** (PN 10) pipe (horizontal pipeline)

Ø pipe [mm]	spacing distances [in cm] at temperature of	
	20 °C	30 °C
20	80	75
25	85	85
32	100	95
40	110	110
50	125	120
63	140	135
75	155	150
90	165	165
110	185	180
125	200	195

Maximum distances of supports of pipeline Ekoplastik **PPR S 3,2** (PN 16) pipe (horizontal pipeline)

Ø pipe [mm]	spacing distances [in cm] at temperature of					
	20°	30°	40°	50°	60°	80°
16	80	75	75	70	70	60
20	90	80	80	80	70	65
25	95	95	95	90	80	75
32	110	105	105	100	95	80
40	120	120	115	105	100	95
50	135	130	125	120	115	100
63	155	150	145	135	130	115
75	170	165	160	150	145	125
90	180	180	170	165	160	135
110	200	195	190	180	175	155
125	220	215	200	195	190	165

Maximum distances of supports of pipeline Ekoplastik **PPR S 2,5** (PN 20) pipe (horizontal pipeline)

Ø pipe [mm]	spacing distances [in cm] at temperature of					
	20°	30°	40°	50°	60°	80°
16	90	85	85	80	80	65
20	95	90	85	85	80	70
25	100	100	100	95	90	85
32	120	115	115	110	100	90
40	130	130	125	120	115	100
50	150	150	140	130	125	110
63	170	160	155	150	145	125
75	185	180	175	160	155	140
90	200	200	185	180	175	150
110	220	215	210	195	190	165
125	235	230	225	210	200	170

Maximum distances of supports of pipeline Ekoplastik **Fiber Basalt Clima** (S 4,S 5), **EVO** (S 3,2, S 4)

Ø pipe [mm]	spacing distances [in cm] at temperature of					
	20°	30°	40°	50°	60°	80°
16	80	75	75	70	70	60
20	85	80	75	75	70	65
25	90	90	90	85	80	75
32	105	100	100	95	90	80
40	115	115	110	105	100	90
50	130	125	120	115	110	95
63	145	140	135	130	125	110
75	160	155	150	140	135	120
90	170	170	160	155	150	130
110	190	185	180	170	165	145
125	205	200	190	185	180	160

Maximum spacing distances Ekoplastik **Stabi Plus, Fiber Basalt Plus** independently of water temperature


Ø pipe [mm]	spacing distances [in cm] at temperature of	
	Ekoplastik Stabi Plus	Ekoplastik Fiber Basalt Plus
16	110	
20	120	90
25	140	110
32	145	120
40	150	130
50	155	140
63	165	160
75	170	165
90	190	180
110	205	190
125	220	200

Maximum spacing distances between supports for vertically oriented pipelines should be multiplied by 1.3.




Pipe fixing


Pipeline route design must be appropriate for the system material, which means that the thermal coefficient of expansion, expansion allowance, given operating conditions (combination of pressure and temperature levels) and the type of pipe joints must be all taken into account. Pipeline systems should be fastened with both fixed and slidably mounted fixture points, allowing for appropriate linear expansion of the pipe.



...at a pipe bend



...at a branching point




...at a fitting installation

Pipe fixing techniques


Pipe fixing is generally done through two types of supports:

Fixed points (FP):


This is a type of fastening where no allowance for pipe expansion is made, i.e. the pipe cannot move along its axis in the place of support (cannot slide).



...by loose pipe-straps
(only for horizontal piping)




...by a sleeve between pipe fittings




...by fixing at fitting places

Sliding point (SP):

This is a type of fixing where the pipe is not allowed to move sideways but expansion movements are not restricted (elongation, shrinkage). Slidable mounting can be designed as follows:



...by loose pipe-straps



...by pipe-straps suspended on hooks

Application of plastic clips




Suitable for H&C water supply



For hot water, the clip must be one size larger than the pipe (needs to be fitted over the insulation).

Other methods of plastic pipeline routing



...by laying the pipe freely into a trough



...by routing the pipe through insulation under plaster (flush-mounting)

System Ekoplastik

Assembly Instructions

Pipeline routing

Pipes should be installed with a minimum gradient of 0.5 % towards the lowest system points, where the system can be vented through a drain faucet or shut off valve with an outlet. The piping system must be divided into separate parts that can be closed if necessary. Straight valves and plastic ball taps are used for this purpose. Shut off valves or ball taps are used when routing under the plaster. It is necessary to test the fittings' functionality (closing/opening) before installation. It is recommended to use a wall mounting group with tap connectors at the end point with installed valve mixers.

It is necessary to open and close the closing fitting three times a year, in order to keep their functionality and tightness.

WALL MOUNTING GROUP WITH TAP CONNECTORS FOR GYPSUM WALL – with exact hole spacing 20 x 1/2" (code SNKK020SXX) is designed for installations where stabilization grooves are not used (e.g. installing into a gypsum wall). The hole spacing is the same as in valve mixers, and it can be adjusted to 100, 135, 150 mm. When routing the piping system into the wall, it is advisable to use the WALL MOUNTING GROUP WITH TAP CONNECTORS 20 x 1/2" (code SNKK020XXX) or 25 x 1/2" (code SNKK025XXX), where the hole spacing is shifted in a way allowing the piping to be adjusted by mounting extensions. For valve mixers it is possible to use spacing of 150, 135, and 100 mm. Using this set ensures the installation process will be fast and precise, without any inaccuracies. If the distribution piping ends with pipe bends, it is necessary to ensure their fixed and accurate positioning. If two wall-mounted bends are installed for


dispensing valve mixers (bath tube, shower and washbasin mixers) their identical height and parallel pipe fitting axis must be ensured. The wall-mounted group with tap connectors must not be exposed to torsion load resulting from dispensing mixers installation. It is therefore recommended to mount the elements to assembling on-wall plates, which helps to keep their exact positioning. The assembling plates have installation holes for plate installation matching the common spacing sizes of dispensing valve mixers.

Routing of Ekoplastik PPR inlet piping

Inlet piping systems are made mainly from 16 – 20 mm diameter pipes, usually laid in wall channels. The channel meant for insulated pipe routing must be free of obstacles and allow some room for expansion. Aside from its thermal properties, the insulation system also protects the pipe against mechanic damage and the insulation layer helps to compensate any piping expansion. It is recommended to use expanded polystyrene or polyurethane (foam) for insulation. Before sealing off the pipes inside the wall, the piping system must be firmly fixed to the channel either by plastic or metal pipe-straps, or by plastering.


If water supply / distribution piping systems are installed inside stack partitions, they must be fixed in a suitable way – such as with a system of metal clips and supporting elements.

The systems must be insulated and correctly positioned, allowing for expansion. If water supply /distribution piping systems are installed inside floor/ceiling structures, then flexible plastic protective sleeves (made of polyethylene) are used for protection against mechanical damage, while the air layer between the sleeve and the pipe works as thermal insulation. Freely laid piping systems are rarely used for short distances in areas




where visual appearance is not a priority (laundry facilities, service areas, etc.). Supporting elements must be positioned with necessary care to fixate the piping and take into account necessary pipe expansion compensation in connecting sections, where the pipes are sealed off. A good piping insulation system is also indispensable (if, for instance, a cold water pipe is laid freely on a wall located in a heated area, there will be a considerable risk of surface condensation). Piping systems may be laid freely on walls where there is no risk of mechanical damage in normal operating conditions.

Routing of Ekoplastik PPR riser piping



...at riser footing with a-slide mounting




...by inserting a loop compensator


In the case of riser piping it is necessary to consider precisely the layout of fixed points and sliding points, as well as create of a suitable expansion compensation system. The adjustments for expansion in riser piping systems are provided as follows.

If it is necessary to divide the riser into several expansion sections, then it can be achieved by placing fixed points. The riser fixed points are always fixed under and over the T-pieces at a branch pipe or a socket, which also prevents the riser from falling. The pipe expansion must be accounted for between these fixed points as follows:

In branching off the feeder piping it is necessary to allow for riser expansion by:



...keeping a sufficient distance from the wall pass-through point




...allowing a certain degree of movement for the branch pipe in the wall pass-through point

Routing of horizontal Ekoplastik PPR piping

With horizontal piping systems, it is necessary to pay very close attention to their expansion conditions and how to lay the piping correctly.


The most common routing is done with galvanised metal or plastic troughs, sleeves, or in-wall channels (these must be kept free from any obstructions).

Expansion is most commonly compensated by a change in the routing or through expansion U-bends, but it is also possible to use a loop compensator for the same purpose. Expansion adjustment may be designed both in perpendicular and parallel plane to the ceiling structures. In the option a) a pipe is insulated together with the trough right on the spot, while in the option b) a fully insulated pipe is laid into the trough. If the pipeline is laid into a galvanized or plastic trough, it is possible to put pipes support in max. length of 2 m.



Routing of Ekoplastik STABI PLUS, FIBER BASALT PLUS inlet piping

STABI PLUS, FIBER BASALT PLUS and FIBER BASALT CLIMA have a three times lesser expansion, higher rigidity and better mechanic resistance than the all-plastic pipes. STABI PLUS, FIBER BASALT PLUS and FIBER BASALT CLIMA can be installed in the same way as the all-plastic systems (as described above), i.e. with conventional expansion adjustments, except with potentially greater support spacing and shorter expansion and adjustment lengths.



...creating a compensating length, allowing for vertical expansion at the riser

System Ekoplastik

Assembly Instructions

When routing inside the in-wall channels, the so-called „rigid“ assembly can be used, which means the pipe is secured to fixed points so the thermal expansion is transferred to the piping material and thus remains unnoticeable. This type of installation however requires firmly anchored sleeves, capable of holding and supporting the piping system.

Coupling to the system

The Ekoplastik pipeline system can be coupled by welding or mechanic coupling. Coupling of pipes and fittings is done in the same way in all types of pipes – the fittings are the same. With Ekoplastik STABI PLUS pipes, it is necessary to remove the upper PPR and middle aluminium layers along the fitting insertion length (using special shavers) before starting any welding operations.

Welding

Polyfusion welding, electrofusion sockets, or butt welding techniques can all be used. All the techniques must be performed accurately and according to standard working procedures, using reliable, well-checked and well-maintained tools.

Pipe cutting

Pipes can be cut by saws or shears. The cutting tools must be in good condition and sharp. Special shears or plastic pipe cutters are recommended.

Threaded couplings, plastic/metal couplings

Plastic/metal couplings in hot water piping and heating systems contain pressed-in brass nickel-coated threads (both external and internal).

If a coupling is not fitted with a hexa- or multigonal piece directly on its metal part, tightening wrenches with a tape should be used.



Warning:

For thermal/technical and physical/mechanical reasons, usage of plastic threaded couplings is not permissible in sanitary engineering. Plastic threaded couplings may be used, for instance, in provisional distribution systems.

Plastic plugs should be used to close elbows for wall mounting and universal wall mounting groups with tap connectors until dispenser pipe fittings (valves) are installed.

Sealing of couplings

Threaded couplings may be sealed with a teflon tape, sealing teflon fibre, or special sealant only.

Insulation

While hot water piping systems and heating systems are insulated against heat loss, the cold water pipes are conversely insulated against heat gain and pipe condensation. Cold water system insulation is necessary, as drinking water health requirements demand that the temperature level be kept under 20 °C. Similarly, the hot water temperature must be below the upper limit given by the standard of protection against scalding, though the temperature limits are also aimed at keeping the bacteria populations under control. Specialized technical solutions aside (such as thermal sterilisation), properly functioning circulation and keeping hot water at the required temperature level are both crucial for protection against bacteria such as Legionella pneumophila.

The thickness and type of insulation layers are determined on the basis of thermal resistance of the insulation system to be used, air humidity in the area of the piping system and the difference between the room temperature (air) and that of the flowing water.

The piping system must be insulated along its whole length, including fittings and valves. It is necessary to maintain a minimum insulation layer thickness along both the pipe diameter and the pipeline length; this means the insulation types that are cut lengthwise to be wrapped over the pipes must be thoroughly sealed after the installation (e.g. using an adhesive, clamps or a sealing tape).

Minimum thermal insulation layer for cold water system – example

Usage of plastic pipes in such systems may therefore present a significant cost-saving solution!

In highly demanding systems (such as in bathrooms, bathtubs, washing machines, etc.) heat losses in plastic pipes with flowing water can be up to 20 % smaller than in metal ones. Another 15% can be saved by thorough insulation. In systems with small and/or short-time demand, where pipes are not regularly heated to operating temperatures, the savings will be smaller (only 10 %) although up to 20% can be expected at peak demand.

The insulation layer thickness for hot water systems usually ranges between 9 and 15 mm at the value of thermal resistance $\lambda = 0.040 \text{ W/mK}$.

Placement / routing of pipes	insulation layer thickness $\lambda = 0.040 \text{ W/mK}$
freely laid pipes in unheated areas (basement areas, for example)	4 mm
freely laid pipes in heated areas	9 mm
pipes in crawlways without concurrently running hot water lines	4 mm
pipes in crawlways with concurrently running hot water lines	13 mm
independently running underplaster pipes (in channels)	4 mm
underplaster pipes (in channels) running in parallel with hot water lines	13 mm
pipes cast over with concrete	4 mm

Note: the above thickness values must be re-calculated for other thermal characteristics

Piping system pressure test

The distribution system can be filled with water no sooner than one hour after the last weld was performed. After the system is complete, a pressure test must be performed under the following conditions:

testing pressure:	min. 1,5 MPa (15 bar)
test commencement:	min. 12 hour after bleeding and additional pressurizing of the system
test duration time:	60 minutes
max. pressure drop:	0,02 MPa (0,2 bar)

Any piping system prepared for this test must be clean, laid according to the design, and visible along its whole length. The system is tested without hydrants and water-meters (flow-meters) and other valves /pipe fittings with the exception of bleeding equipment.

Already installed closing valves should be left open. Water dispensing fittings may be installed only if they conform to the testing pressure; though under standard conditions they are usually replaced with plugs. The piping system is filled from the lowest point so that all bleeding points are open from the beginning and then sequentially closed once water running out of them is without air bubbles. The pipeline testing length is usually determined depending on local conditions, with recommended max. length being 100 metres. After filling the system with water the internal water system is stabilized with operating overpressure for least 12 hours; after this period the overpressure is increased to 15 bars (testing overpressure). The pressure test lasts 60 minutes and maximum allowable pressure drop is 0.02 MPa. If the value of pressure drop is higher then the leak must be discovered, relevant defect fixed, and a new pressure test must be performed.

Central heating system pressure test

Pressure test is performed under the maximum allowable pressure specified in the project. The system is filled with water, the air contained inside is bled, and then the entire system and the connected equipment (including fittings, radiators, valves, etc.) is inspected in detail, making sure there is no visible leakage. The system must remain filled for at least 6 hours, after which a new inspection is performed. The test is considered to be successful if no leaks are discovered during this inspection.

Underfloor heating pressure test

Before laying the load distribution layer a pressure test must be performed in order to check the heating circuits for any potential leaks. The testing pressure is 0.6 MPa and the testing duration is 24 hours. The pressure test must be properly recorded, e.g. in accordance with the pressure test report shown on page 29 (this record is part of the documentation required for any potential claim process).

System Ekoplastik


Material Transport and Storage

Protection

The system components must be protected against weather, UV radiation and contamination.

Stores of plastic components must be separated from such areas where solvents, adhesives, paints or similar products are stored.

It is recommended to store the components at minimum temperature of 5 °C. If the temperature is lower than 5 °C, it is necessary to be careful at pipeline manipulation.




Plastic pipes in stock must be supported along their whole lengths or protected in another suitable way against deflection. Plastic pipe fittings are usually stored in sacks on palettes or freely loaded in boxes, containers, baskets,

etc. Maximum storage height of one metre must be respected if plastic pipes are stored in plastic sleeves and/or pipe fittings in plastic sacks. Each of the different types of pipes and fittings are stored separately. When dispatching from storage, the oldest stock should be dispatched first.

During their transport it is not allowed to drag pipes over the ground or lorry deck. The components/pipes must not be transported by throwing or letting them fall off the lorry to the ground. If they are transported to/on the site then they must be protected against mechanical damage and stored at the spot on a suitable underlay where protected against dirt, solvents, direct heat (contact with a radiator, etc.).

The components are supplied in protective covers (pipes in polyethylene bags, pipe fittings also in sacks or cardboard boxes) and it is desirable to let them in these as long as possible before the start of installation works (to protect them against dirt and other contamination).



Safety welding principles

① Welder is an electrical equipment. The condition of safe use consists of the electrical connection in manner prescribed by standard (three-wire system, in socket with earthing contact with the corresponding current load).

② The electrical installation must be equipped with properly chosen overload protection.

③ The power cord must be protected against mechanical damage and burning of insulation cover.

④ Welder must be protected against humidity and direct contact with water.

⑤ Welder shall not be used in flammable and explosive environment.

⑥ Welder must be handled carefully, and protected against hitting, throwing, inappropriate pulling the cord.

⑦ In case the welder does not work properly, you must immediately unplug it from source of electric power. Damaged welder must be sent back to the manufacturer or seller together with an accurate description of the defect.

⑧ Operation with the welder requires special caution because of the high temperature of its body and nozzles.

⑨ Never leave the welder unattended while energized.

⑩ The welding process should always be performed in a well-aired room (due to the vapors formed during heating and melting of plastic elements while welding).

Pressure Test Certificate

Description of installed system:.....

Place:.....

Building / structure:.....

Installed lenght of piping systems

Ekoplastik pipe diameter [mm]	pipe / line length [m]	pressure class	description of pipe
16			
20			
25			
32			
40			
50			
63			
75			
90			
110			
125			

The highest outlet point.....m above pressure gauge

Test started on / day: time:

Testing pressure: MPa

Pressure after 1 hour: MPa

Pressure drop during the test MPa

Result:

Client: (signature confirms the installation was accepted without defects)

.....

place

.....

date

.....

rubber stamp & signature

Contractor:.....

.....

place

.....

date

.....

rubber stamp & signature

System Ekoplastik

Polyfusion Welding Working Procedures

Tools

- ① Electric polyfusion welding machine fitted with welding adapters of suitable dimensions, incl. a movable feeder cable.
- ② Contact thermometer.
- ③ Special shears or cutter (i.e. jaw with a cutting wheel); metal hand saw if nothing else is available.
- ④ Sharp penknife with short blade.
- ⑤ Textile rag (non-synthetic material only).
- ⑥ Degreaser (Tangit, Spirit).
- ⑦ Folding ruler + marker.
- ⑧ Scraper and assembly jig for welding of diameters over 50 mm.
- ⑨ Pipe shaver (when welding Ekoplastik Stabi pipes).

Tool check

First, attach the welding adapter to the welding machine (usually done with screws, depending on the type of the welding machine). With the welder controller set the temperature at 250 – 270 °C and connect the power supply. Time necessary to heat up the welding machine will depend on ambient conditions. Once the welding machine is warm, clean the welding adapters of impurities left from the previous use with a rag made from non-synthetic textile; failure to do so may damage the teflon surfaces. You may start working with the welding apparatus when it is sufficiently hot, which you can check using the LED diode or a contact thermometer. Use the contact thermometer if you need to fine-tune the temperature up to 250 – 270 °C. Check the proper functionality of the special shears or cutting wheel by making two cuts on a pipe assigned for testing purposes. The trial cutting should not deform or depress the outer diameter of the pipe; if it does, the tools need to be sharpened further.

Materials check

All the material should be inspected thoroughly prior to welding. The com-

ponents must not contain any wall thinning defects and closing elements should be checked if they function properly and correspond to their matching piece. Welding sockets and the end of the pipe to be inserted into the fitting should be cleaned and degreased. Test the fittings by sliding them on the heating plug (which of course must remain cold for now) and check if they are not too loose. Wobbly fittings must be discarded!

Welding process

- ① Measure and cut off a piece of pipe of a desirable length. When using a metal hand saw, make sure to clean the burr and dross from the pipe's edge.



- ② It is also recommended to bevel the outer edges of the pipe that we mean to heat up. Use of a special cutter or a sharp knife at approximate angle

of 30 – 45 degrees. This procedure is strongly recommended especially for pipe diameters over 40 mm. This modification will prevent the material from bunching up when the pipe end is inserted into a fitting.

- ③ If you are welding components from Ekoplastik Stabi, make sure to first remove the outer PPR and middle aluminium layers (using special shavers) along the whole section of the pipe to be inserted into the fitting's socket. The cleaned pipe then can be handled in the same way as the all-plastic pipes Ekoplastik PPR.



- ④ If you are welding larger diameters (40 mm and more) it is recommended that you check their ovality first. You should also scrape off the oxidized surface layer (about 0,1 mm in depth) along the whole length of the pipe to be inserted. The oxidized material can have negative effect on the weld quality.




⑤ The insertion depth of the pipe (to be inserted into a pipe fitting) should be marked with a marker or a sharpie. Keep in mind that the pipe must not be pushed into the fitting socket as far as it can possibly go. About a 1mm gap should be preserved for material accumulation so as not to reduce the fitting's intern.



⑥ Furthermore, it is recommended that you also mark the weld position on both the pipe and the fitting, in order to prevent the pipe from rotating after insertion. You can also use installation marks on fittings for the same purpose.

⑦ The surfaces to be welded should be cleaned and degreased after the marking is complete. If this step is left out, then the melted layers may bond inadequately! Now you can begin the heating-up process.



⑧ Due to its thicker walls, the fitting needs more time to heat up properly and should be put on the welding adapter first. Check if it is not too loose once again; a fitting that wobbles or does not fit the whole surface of the adapter should be discarded because uneven contact (and subsequent une-

ven heat up of the material) may result in poor-quality welds. Next slide the pipe onto the adapter and repeat the same procedure as with the fitting.



be welded while holding them in your hand; for the larger diameters (50 mm and more) machine welding or at least a welding jig is recommended in order to ensure sufficient pressure and correct alignment of the pipes.

Preparation of pipes



bevelling



scraping

Welding



fixing and aligning the components, then heating them up



adjustment after the heating period



finished weld after the cool-down

Recommendation for welding operations involving large diameters:

Pipes up to 40 mm in diameter may



System Ekoplastik

Polyfusion Welding Working Procedures

The minimum ambient temperature for welding is + 5°C

D [mm]	insertion depth L (mm)	heat-up time [s]	time for adjustment [s]	cooling time	
				fixation (s)	total (min)
16	13	5	4	6	2
20	14	5	4	6	2
25	15	7	4	10	2
32	17	8	6	10	4
40	18	12	6	20	4
50	20	18	6	20	4
63	26	24	8	30	6
75	29	30	8	30	6
90	32	40	8	40	6
110	35	50	10	50	8
125	41	60	10	60	8

Coefficient of Loss ζ

	→	Socket	ζ 0,2		→	Tee reduced – pasassage in case of flow	ζ 1,1
	→	Reduction by 2 dimension	ζ 0,55		↓	Tee reduced separation of flow	ζ 4,3
	→	Elbow 90°	ζ 1,5		→	Reducing sleeve with metal thread	ζ 0,4
	→	Tee – passage in case of separation of flow	ζ 1,1		→	Metal reducer with cap nut	ζ 8,3
	↓	Tee – separation of flow	ζ 1,5				

Welding With Electrofusion Sockets - Working Procedures

Tools

- ① **Electrofusion welding machine for electric welding of plastic pipes (electrofusion socket welder)**
- ② **Special shears or cutter.**
- ③ **Textile rag (non-synthetic material only).**
- ④ **Degreaser, sharp knife with short blade.**
- ⑤ **Folding ruler + marker**
- ⑥ **Welding jig to secure the pipe and fitting and ensure their correct alignment.**
- ⑦ **Scraper and assembly jig for welding of diameters over 50 mm.**
- ⑧ **Pipe shaver (when welding Ekoplastik Stabi pipes).**



Preparing the tools

Place the welding machine at your workplace and unreel the power cable. Check your cutting tools (for details see Chapter 13: Polyfusion Welding).

Welding process

Check the pipe and the fitting and prepare the welding machine.

Prepare the pipe of required length and remove the oxidized layer with a scraper or special agent. Degrease the external surface of the pipe and internal surface of the electrofusion socket (use alcohol or Tangit).

After you are done, mark the pipe insertion depth (depth of insertion inside the electrofusion socket). If you are working with the Ekoplastik Stabi piping, then make sure to remove the outer PPR and middle aluminium layers first, using a special shaver along the whole pipe section to be inserted into the socket. Insert the pipe into the electrofusion socket.

Make sure the pipe is firmly fixed in the socket because due to the volume expansion of heated plastic material the pipe could be pushed out of its place during the heating process. Connect the electrofusion welding machine to the power supply (220V) and wait until the welding machine gets into operational state. Then connect the contacts of the electrofusion socket and welding machine. Welding starts after you push the START button; the welding machine switches off automatically after the weld is completed. You can tell the electrofusion welding is proceeding well if the excess plastic material is being squeezed out of the check-points on the socket's surface. The newly coupled piping system may be filled with water not earlier than one hour after the last weld has been completed.

It is very important to let the new joint cool down before exposing it to any strain. The weld should be also protected from mechanical tension (pipe's rotation or pull).

System Ekoplastik

Repair of Damaged Piping

- ① A unique way of repairing pipes drilled through – should be a part of every plumber's kit.
- ② Considerably reduces the extent of demolition work and damage to tiles.
- ③ The set includes a special heating adapter and repairing stakes.
- ④ The adapter is universally compatible with all types of non-paired welding machines incl. the angle welding machines.
- ⑤ A special non-paired adapter is now part of the welding set.
- ⑥ The set is intended for repair of drilled through pipelines Ekoplastik PPR and Ekoplastik Stabi.
- ⑦ It is a universal fit for all diameters between 20 and 125 mm, as well as for all pressure lines.
- ⑧ It operates on the principle of polyfusion welding and all general rules for polyfusion welding are applicable – see the General Rules for polyfusion welding.



Required tools

Repairing set, piece of cloth or napkin for degreasing and drying out, tape measure, pencil, screwdriver, scissors (pliers), special welding adapters, correcting spike and welding machine. Turn on the welding machine with the welding adapter attached, set it to the maximum and wait at least for the second heat-up cycle.



- ① The drilled hole must be redrilled (calibrated) with a 10 mm drill.



- ② Dry and degrease. Measure and mark the depth of insertion on the stake depending on the wall thickness of the drilled through pipe + 2 mm; set the distance ring on the heating adaptor.



- ④ Take down the repairing stake and insert without turning into the heated hole.



- ③ Start heating the repairing stake and adaptor and insert the heating stake slowly and without turning into the prepared hole. Heat for 5 sec.



- ⑤ When it cools down, cut off the remaining part of the repairing stake with a pair of shears.

If you have no previous experience with the repair set, we recommend that you test it out with two test welds, cut them and visually check the weld – both the quality of the fusion and the size of melted collars.


Additional Branching

- ① The large assortment of fittings allows to create a 32 or 40 mm diameter branching or branching with both internal and external thread (3/4").
- ② For all Ekoplastik PPR and Ekoplastik Stabi pipelines with diameters 63, 75, 90, 110, 125 mm and for all pressure lines.
- ③ The principle of polyfusion welding type C is maintained.
- ④ Special heating adaptors for each pipeline diameter; universal for all types of flat welding machines.
- ⑤ Saves work and space – replaces the T-pieces and reducers.
- ⑥ Connecting the saddle and the pipe ensures a perfectly connected joint throughout the entire welding area.


Useful tools




All-plastic
weld-in saddle



Weld-in saddle
with metal thread female



Weld-in saddle
with metal thread male



① Drill a hole into the pipe with the special drill.

② Clean. If you use the Stabi pipe, chamfer the edge of the drilled hole. Clean and degrease the weld-in saddle as well as the drilled hole.

③ Put the plastic weld-in saddle on the adapter so that the mark on the saddle and the mark on the adapter are aligned. Heat-up the hole and the plastic weld-in saddle. The heating period is the

same as with the 32 mm diameter (8 sec.). For weld-in saddle parts 110x32 and 110x40 mm the heating-up period is the same as for the 40 mm ones (12 sec.) 125x50, 125x60 mm (24 sec.).

④ Put the heated saddle on the heated hole and fasten for about 16 sec. You can fill the pipe with water and expose it to pressure one hour later.



Pressure Loss Tables

PPR S 5 (PN10) water temperature = 10 °C

k=0,01	20 x 2,3 mm		25 x 2,5 mm		32 x 3,0 mm		40 x 3,7 mm		50 x 4,6 mm		63 x 5,8 mm		75 x 6,9 mm		90 x 8,2 mm		110 x 10 mm		125 x 11,4 mm		
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s																	
0,01	0,006	0,1																			
0,02	0,020	0,1	0,006	0,1																	
0,03	0,041	0,2	0,012	0,1	0,003	0,1															
0,04	0,067	0,2	0,019	0,1	0,006	0,1															
0,05	0,099	0,3	0,029	0,2	0,008	0,1	0,003	0,1													
0,06	0,137	0,3	0,039	0,2	0,011	0,1	0,004	0,1													
0,07	0,180	0,4	0,052	0,2	0,015	0,1	0,005	0,1	0,002	0,1											
0,08	0,227	0,4	0,065	0,3	0,019	0,2	0,006	0,1	0,002	0,1											
0,09	0,280	0,5	0,080	0,3	0,023	0,2	0,008	0,1	0,003	0,1											
0,10	0,337	0,5	0,097	0,3	0,028	0,2	0,009	0,1	0,003	0,1											
0,12	0,465	0,6	0,133	0,4	0,038	0,2	0,013	0,1	0,004	0,1	0,001	0,1									
0,14	0,611	0,8	0,175	0,4	0,050	0,3	0,017	0,2	0,006	0,1	0,002	0,1									
0,16	0,774	0,9	0,222	0,5	0,063	0,3	0,022	0,2	0,007	0,1	0,002	0,1	0,001	0,1							
0,18	0,954	1,0	0,273	0,6	0,078	0,3	0,027	0,2	0,009	0,1	0,003	0,1	0,001	0,1							
0,20	1,150	1,1	0,329	0,6	0,094	0,4	0,032	0,2	0,011	0,2	0,004	0,1	0,002	0,1							
0,30	2,370	1,6	0,674	1,0	0,192	0,6	0,065	0,4	0,022	0,2	0,007	0,1	0,003	0,1	0,001	0,1					
0,40	3,971	2,1	1,124	1,3	0,319	0,8	0,108	0,5	0,037	0,3	0,012	0,2	0,005	0,1	0,002	0,1	0,001	0,1			
0,50	5,939	2,7	1,675	1,6	0,474	0,9	0,160	0,6	0,055	0,4	0,018	0,2	0,008	0,2	0,003	0,1	0,001	0,1			
0,60	8,266	3,2	2,322	1,9	0,655	1,1	0,221	0,7	0,076	0,5	0,025	0,3	0,011	0,2	0,005	0,1	0,002	0,1			
0,70			3,064	2,2	0,863	1,3	0,291	0,8	0,099	0,5	0,033	0,3	0,014	0,2	0,006	0,2	0,002	0,1			
0,80			3,900	2,5	1,095	1,5	0,369	1,0	0,126	0,6	0,042	0,4	0,018	0,3	0,008	0,2	0,003	0,1	0,002	0,1	
0,90			4,826	2,9	1,352	1,7	0,455	1,1	0,155	0,7	0,051	0,4	0,022	0,3	0,009	0,2	0,004	0,1	0,002	0,1	
1,00			5,844	3,2	1,634	1,9	0,549	1,2	0,187	0,8	0,062	0,5	0,027	0,3	0,011	0,2	0,004	0,2	0,002	0,1	
1,20					2,269	2,3	0,760	1,4	0,258	0,9	0,085	0,6	0,037	0,4	0,015	0,3	0,006	0,2	0,003	0,1	
1,40					2,998	2,6	1,001	1,7	0,340	1,1	0,112	0,7	0,049	0,5	0,020	0,3	0,008	0,2	0,004	0,1	
1,60					3,819	3,0	1,273	1,9	0,431	1,2	0,142	0,8	0,062	0,5	0,026	0,4	0,010	0,3	0,005	0,2	
1,80					4,732	3,4	1,574	2,2	0,532	1,4	0,175	0,9	0,076	0,6	0,031	0,4	0,012	0,3	0,006	0,2	
2,00							1,903	2,4	0,642	1,5	0,211	1,0	0,092	0,7	0,038	0,5	0,014	0,3	0,008	0,2	
2,20							2,262	2,6	0,762	1,7	0,250	1,1	0,108	0,7	0,045	0,5	0,017	0,3	0,009	0,3	
2,40							2,649	2,9	0,891	1,8	0,292	1,2	0,126	0,8	0,052	0,6	0,020	0,4	0,010	0,3	
2,60							3,064	3,1	1,029	2,0	0,337	1,3	0,146	0,9	0,060	0,6	0,023	0,4	0,012	0,3	
2,80							3,507	3,4	1,176	2,1	0,385	1,3	0,166	1,0	0,069	0,7	0,026	0,4	0,014	0,3	
3,00									1,332	2,3	0,436	1,4	0,188	1,0	0,078	0,7	0,030	0,5	0,016	0,4	
3,20									1,497	2,4	0,489	1,5	0,211	1,1	0,087	0,8	0,033	0,5	0,018	0,4	
3,40									1,671	2,6	0,545	1,6	0,235	1,2	0,097	0,8	0,037	0,5	0,019	0,4	
3,60									1,854	2,8	0,604	1,7	0,260	1,2	0,107	0,8	0,041	0,6	0,022	0,4	
3,80									2,045	2,9	0,666	1,8	0,287	1,3	0,118	0,9	0,045	0,6	0,024	0,5	
4,00									2,246	3,1	0,731	1,9	0,314	1,4	0,129	0,9	0,049	0,6	0,026	0,5	
4,20									2,454	3,2	0,798	2,0	0,343	1,4	0,141	1,0	0,054	0,7	0,028	0,5	
4,40									2,672	3,4	0,868	2,1	0,373	1,5	0,153	1,0	0,058	0,7	0,031	0,5	
4,60									2,898	3,5	0,940	2,2	0,404	1,6	0,166	1,1	0,063	0,7	0,034	0,6	
4,80										1,016	2,3	0,436	1,6	0,179	1,1	0,068	0,8	0,037	0,6		
5,00										1,093	2,4	0,469	1,7	0,193	1,2	0,073	0,8	0,039	0,6		
5,20												0,492	1,8	0,203	1,2	0,078	0,8	0,041	0,6		
5,40												0,523	1,8	0,218	1,3	0,083	0,9	0,045	0,7		
5,60												0,560	2,0	0,234	1,3	0,088	0,9	0,048	0,7		
5,80												0,598	2,0	0,247	1,4	0,094	0,9	0,051	0,7		
6,00												0,637	2,0	0,264	1,4	0,099	0,9	0,054	0,7		
6,20												0,672	2,1	0,281	1,5	0,105	1,0	0,058	0,8		
6,40												0,714	2,2	0,295	1,5	0,113	1,0	0,061	0,8		
6,60												0,757	2,2	0,313	1,6	0,119	1,0	0,064	0,8		
6,80												0,801	2,3	0,332	1,6	0,125	1,1	0,068	0,8		
7,00												0,831	2,4	0,351	1,7	0,132	1,1	0,071	0,9		

k - roughness | **Q** - flow | **R** - pressure loss by rubbing | **v** - flow rate

Pressure Loss Tables

PPR S 3,2 (PN16) water temperature = 50° C

k=0,01	16 x 2,3 mm		20 x 2,8 mm		25 x 3,5 mm		32 x 4,5 mm		40 x 5,6 mm		50 x 6,9 mm		63 x 8,7 mm		75 x 10,4 mm		90 x 12,5 mm		110 x 15,2 mm		125 x 17,1 mm	
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s												
0,02	0,068	0,2	0,022	0,1	0,008	0,1																
0,04	0,230	0,4	0,075	0,2	0,026	0,2	0,008	0,1	0,003	0,1												
0,06	0,473	0,6	0,154	0,4	0,053	0,2	0,016	0,1	0,006	0,1	0,002	0,1										
0,08	0,792	0,8	0,257	0,5	0,088	0,3	0,027	0,2	0,009	0,1	0,003	0,1										
0,10	1,183	1,0	0,382	0,6	0,131	0,4	0,040	0,2	0,014	0,2	0,005	0,1	0,002	0,1								
0,12	1,644	1,2	0,530	0,7	0,181	0,5	0,056	0,3	0,019	0,2	0,006	0,1	0,002	0,1	0,001	0,1						
0,14	2,175	1,4	0,698	0,9	0,238	0,6	0,073	0,3	0,025	0,2	0,008	0,1	0,003	0,1	0,001	0,1						
0,16	2,773	1,6	0,888	1,0	0,302	0,6	0,093	0,4	0,032	0,2	0,011	0,2	0,004	0,1	0,002	0,1						
0,18	3,439	1,8	1,099	1,1	0,373	0,7	0,115	0,4	0,039	0,3	0,013	0,2	0,004	0,1	0,002	0,1	0,001	0,1				
0,20	4,172	2,0	1,330	1,2	0,450	0,8	0,138	0,5	0,047	0,3	0,016	0,2	0,005	0,1	0,002	0,1	0,001	0,1				
0,30	8,828	2,9	2,785	1,8	0,935	1,2	0,285	0,7	0,096	0,5	0,032	0,3	0,011	0,2	0,005	0,1	0,002	0,1	0,001	0,1		
0,40		4,731	2,5	1,578	1,6	0,478	1,0	0,161	0,6	0,054	0,4	0,018	0,2	0,008	0,2	0,003	0,1	0,001	0,1			
0,50		7,161	3,1	2,376	2,0	0,716	1,2	0,240	0,8	0,080	0,5	0,026	0,3	0,012	0,2	0,005	0,2	0,002	0,1			
0,60				3,325	2,4	0,997	1,4	0,334	0,9	0,110	0,6	0,036	0,4	0,016	0,3	0,007	0,2	0,003	0,1			
0,70				4,425	2,8	1,322	1,7	0,441	1,1	0,146	0,7	0,048	0,4	0,021	0,3	0,009	0,2	0,003	0,1			
0,80				5,675	3,1	1,689	1,9	0,562	1,2	0,185	0,8	0,061	0,5	0,026	0,3	0,011	0,2	0,004	0,2	0,002	0,1	
0,90				7,073	3,5	2,098	2,2	0,696	1,4	0,229	0,9	0,075	0,6	0,033	0,4	0,014	0,3	0,005	0,2	0,003	0,1	
1,00					2,549	2,4	0,843	1,5	0,277	1,0	0,091	0,6	0,039	0,4	0,016	0,3	0,006	0,2	0,003	0,1		
1,20					3,577	2,9	1,178	1,8	0,385	1,2	0,126	0,7	0,055	0,5	0,023	0,4	0,009	0,2	0,005	0,2		
1,40					4,770	3,4	1,565	2,1	0,510	1,4	0,166	0,9	0,072	0,6	0,030	0,4	0,011	0,3	0,006	0,2		
1,60						2,004	2,5	0,650	1,6	0,211	1,0	0,091	0,7	0,038	0,5	0,014	0,3	0,008	0,3			
1,80						2,494	2,8	0,807	1,7	0,261	1,1	0,113	0,8	0,047	0,5	0,018	0,4	0,009	0,3			
2,00						3,036	3,1	0,980	1,9	0,316	1,2	0,136	0,9	0,057	0,6	0,021	0,4	0,011	0,3			
2,20						3,629	3,4	1,168	2,1	0,376	1,3	0,162	1,0	0,067	0,7	0,025	0,4	0,013	0,3			
2,40								1,372	2,3	0,441	1,5	0,190	1,0	0,079	0,7	0,030	0,5	0,015	0,4			
2,60								1,592	2,5	0,511	1,6	0,220	1,1	0,091	0,8	0,034	0,5	0,018	0,4			
2,80								1,828	2,7	0,585	1,7	0,251	1,2	0,104	0,8	0,039	0,6	0,020	0,5			
3,00								2,079	2,9	0,664	1,8	0,285	1,3	0,118	0,9	0,044	0,6	0,023	0,5			
3,20								2,345	3,1	0,748	2,0	0,320	1,4	0,132	1,0	0,050	0,6	0,025	0,5			
3,40								2,627	3,3	0,837	2,1	0,358	1,5	0,148	1,0	0,055	0,7	0,029	0,6			
3,60								2,925	3,5	0,930	2,2	0,398	1,6	0,164	1,1	0,061	0,7	0,032	0,6			
3,80										1,028	2,3	0,439	1,6	0,181	1,1	0,067	0,8	0,035	0,6			
4,00										1,131	2,4	0,483	1,7	0,198	1,2	0,074	0,8	0,039	0,7			
4,20										1,239	2,6	0,528	1,8	0,217	1,3	0,081	0,8	0,042	0,7			
4,40										1,351	2,7	0,575	1,9	0,236	1,3	0,088	0,9	0,046	0,7			
4,60										1,468	2,8	0,624	2,0	0,256	1,4	0,095	0,9	0,050	0,7			
4,80										1,589	2,9	0,676	2,1	0,277	1,4	0,103	1,0	0,053	0,8			
5,00										1,716	3,1	0,729	2,2	0,298	1,5	0,111	1,0	0,057	0,8			
5,20												0,774	2,3	0,318	1,6	0,117	1,0	0,062	0,8			
5,40												0,832	2,3	0,341	1,6	0,127	1,1	0,066	0,9			
5,60												0,893	2,4	0,365	1,7	0,136	1,1	0,070	0,9			
5,80												0,949	2,5	0,389	1,8	0,145	1,2	0,076	0,9			
6,00												1,014	2,6	0,414	1,8	0,154	1,2	0,081	0,9			
6,20												1,081	2,7	0,440	1,9	0,164	1,3	0,086	1,0			
6,40												1,142	2,8	0,467	1,9	0,173	1,3	0,091	1,0			
6,60												1,212	2,9	0,494	2,0	0,183	1,3	0,096	1,0			
6,80												1,285	3,0	0,522	2,1	0,194	1,4	0,101	1,1			
7,00												1,351	3,0	0,551	2,1	0,204	1,4	0,107	1,1			

PPR S 2,5 (PN20) water temperature = 10° C

k=0,01	16 x 2,7 mm		20 x 3,4 mm		25 x 4,2 mm		32 x 5,4 mm		40 x 6,7 mm		50 x 8,4 mm		63 x 10,5 mm		75 x 12,5 mm		90 x 15,0 mm		110 x 18,4 mm		125 x 20,8 mm								
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s																	
0,02	0,118	0,2	0,041	0,1	0,014	0,1	0,004	0,1																					
0,04	0,399	0,5	0,140	0,3	0,047	0,2	0,015	0,1	0,005	0,1																			
0,06	0,816	0,7	0,286	0,4	0,096	0,3	0,030	0,2	0,010	0,1	0,004	0,1																	
0,08	1,357	0,9	0,475	0,6	0,159	0,4	0,050	0,2	0,017	0,1	0,006	0,1	0,002	0,1															
0,10	2,017	1,1	0,704	0,7	0,236	0,5	0,073	0,3	0,025	0,2	0,009	0,1	0,003	0,1	0,001	0,1													
0,12	2,791	1,4	0,973	0,9	0,325	0,6	0,101	0,3	0,034	0,2	0,012	0,1	0,004	0,1	0,002	0,1													
0,14	3,676	1,6	1,279	1,0	0,427	0,6	0,133	0,4	0,045	0,3	0,016	0,2	0,005	0,1	0,002	0,1	0,001	0,0											
0,16	4,669	1,8	1,622	1,2	0,540	0,7	0,168	0,5	0,057	0,3	0,020	0,2	0,006	0,1	0,003	0,1	0,001	0,1											
0,18	5,768	2,0	2,000	1,3	0,665	0,8	0,206	0,5	0,070	0,3	0,024	0,2	0,008	0,1	0,003	0,1	0,001	0,1											
0,20	6,971	2,3	2,414	1,5	0,802	0,9	0,249	0,6	0,084	0,4	0,029	0,2	0,010	0,1	0,004	0,1	0,002	0,1											
0,30	14,522	3,4	4,994	2,2	1,650	1,4	0,510	0,8	0,172	0,5	0,060	0,3	0,019	0,2	0,008	0,2	0,004	0,1	0,001	0,1									
0,40		8,397	2,9	2,761	1,8	0,849	1,1	0,286	0,7	0,099	0,5	0,032	0,3	0,014	0,2	0,006	0,1	0,002	0,1										
0,50				4,125	2,3	1,264	1,4	0,425	0,9	0,147	0,6	0,048	0,4	0,021	0,3	0,009	0,2	0,003	0,1										
0,60					5,735	2,8	1,752	1,7	0,587	1,1	0,203	0,7	0,066	0,4	0,029	0,3	0,012	0,2	0,005	0,1									
0,70						7,585	3,2	2,311	2,0	0,773	1,3	0,267	0,8	0,087	0,5	0,038	0,4	0,016	0,2	0,006	0,2								
0,80							2,939	2,3	0,981	1,4	0,338	0,9	0,110	0,6	0,048	0,4	0,020	0,3	0,008	0,2	0,004	0,2							
0,90							3,635	2,5	1,211	1,6	0,417	1,0	0,135	0,6	0,059	0,5	0,025	0,3	0,010	0,2	0,005	0,2							
1,00							4,399	2,8	1,463	1,8	0,503	1,2	0,163	0,7	0,071	0,5	0,030	0,4	0,011	0,2	0,006	0,2							
1,20							6,127	3,4	2,031	2,2	0,696	1,4	0,225	0,9	0,097	0,6	0,041	0,4	0,016	0,3	0,008	0,2							
1,40								2,683	2,5	0,917	1,6	0,296	1,0	0,128	0,7	0,054	0,5	0,021	0,3	0,011	0,3								
1,60								3,417	2,9	1,165	1,8	0,375	1,2	0,162	0,8	0,068	0,6	0,026	0,4	0,013	0,3								
1,80								4,233	3,2	1,441	2,1	0,463	1,3	0,200	0,9	0,083	0,6	0,032	0,4	0,017	0,3								
2,00									1,742	2,3	0,559	1,4	0,241	1,0	0,101	0,7	0,039	0,5	0,021	0,4									
2,20									2,070	2,5	0,663	1,6	0,286	1,1	0,119	0,8	0,046	0,5	0,024	0,4									
2,40									2,423	2,8	0,775	1,7	0,334	1,2	0,139	0,8	0,054	0,6	0,028	0,4									
2,60									2,803	3,0	0,894	1,9	0,385	1,3	0,160	0,9	0,062	0,6	0,033	0,5									
2,80									3,208	3,2	1,022	2,0	0,440	1,4	0,183	1,0	0,070	0,7	0,037	0,5									
3,00									3,638	3,5	1,158	2,2	0,498	1,5	0,207	1,1	0,080	0,7	0,042	0,6									
3,20										1,301	2,3	0,559	1,6	0,232	1,1	0,089	0,8	0,047	0,6										
3,40										1,452	2,5	0,623	1,7	0,259	1,2	0,099	0,8	0,052	0,6										
3,60										1,610	2,6	0,691	1,8	0,286	1,3	0,110	0,9	0,058	0,7										
3,80										1,776	2,7	0,761	1,9	0,316	1,3	0,121	0,9	0,064	0,7										
4,00										1,949	2,9	0,835	2,0	0,346	1,4	0,133	1,0	0,069	0,7										
4,20										2,131	3,0	0,912	2,1	0,377	1,5	0,145	1,0	0,076	0,8										
4,40										2,319	3,2	0,992	2,2	0,410	1,6	0,157	1,0	0,083	0,8										
4,60										2,515	3,3	1,075	2,3	0,444	1,6	0,170	1,1	0,089	0,8										
4,80										2,718	3,5	1,161	2,4	0,480	1,7	0,184	1,1	0,097	0,9										
5,00											1,251	2,5	0,516	1,8	0,198	1,2	0,105	0,9											
5,20											1,332	2,7	0,548	1,8	0,207	1,2	0,111	1,0											
5,40											1,426	2,8	0,587	1,9	0,222	1,3	0,120	1,0											
5,60											1,522	2,9	0,626	2,0	0,235	1,3	0,128	1,0											
5,80											1,622	3,0	0,667	2,1	0,251	1,4	0,135	1,1											
6,00											1,735	3,1	0,710	2,1	0,268	1,4	0,145	1,1											
6,20												0,753	2,2	0,285	1,5	0,152	1,1												
6,40												0,797	2,3	0,300	1,5	0,162	1,2												
6,60												0,843	2,3	0,318	1,6	0,172	1,2												
6,80												0,897	2,4	0,336	1,6	0,179	1,2												
7,00												0,945	2,5	0,352	1,7	0,190	1,3												

Pressure Loss Tables

PPR S 2,5 (PN20) water temperature = 50° C

k=0,01	16 x 2,7 mm		20 x 3,4 mm		25 x 4,2 mm		32 x 5,4 mm		40 x 6,7 mm		50 x 8,4 mm		63 x 10,5 mm		75 x 12,5 mm		90 x 15,0 mm		110 x 18,4 mm		125 x 20,8 mm			
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s												
0,02	0,096	0,2	0,034	0,1	0,011	0,1	0,004	0,1																
0,04	0,326	0,5	0,114	0,3	0,038	0,2	0,012	0,1	0,004	0,1														
0,06	0,672	0,7	0,234	0,4	0,078	0,3	0,024	0,2	0,008	0,1	0,003	0,1												
0,08	1,126	0,9	0,390	0,6	0,130	0,4	0,040	0,2	0,014	0,1	0,005	0,1	0,002	0,1										
0,10	1,684	1,1	0,582	0,7	0,193	0,5	0,060	0,3	0,020	0,2	0,007	0,1	0,002	0,1	0,001	0,1								
0,12	2,344	1,4	0,807	0,9	0,267	0,6	0,082	0,3	0,028	0,2	0,010	0,1	0,003	0,1	0,001	0,1								
0,14	3,104	1,6	1,065	1,0	0,351	0,6	0,108	0,4	0,037	0,3	0,013	0,2	0,004	0,1	0,002	0,1	0,001	0,0						
0,16	3,962	1,8	1,356	1,2	0,446	0,7	0,137	0,5	0,046	0,3	0,016	0,2	0,005	0,1	0,002	0,1	0,001	0,1						
0,18	4,918	2,0	1,679	1,3	0,551	0,8	0,169	0,5	0,057	0,3	0,020	0,2	0,006	0,1	0,003	0,1	0,001	0,1						
0,20	5,972	2,3	2,033	1,5	0,666	0,9	0,204	0,6	0,069	0,4	0,024	0,2	0,008	0,1	0,003	0,1	0,001	0,1						
0,30	12,680	3,4	4,273	2,2	1,388	1,4	0,423	0,8	0,141	0,5	0,049	0,3	0,016	0,2	0,007	0,2	0,003	0,1	0,001	0,1				
0,40			7,281	2,9	2,348	1,8	0,710	1,1	0,236	0,7	0,081	0,5	0,026	0,3	0,011	0,2	0,005	0,1	0,002	0,1				
0,50					3,541	2,3	1,065	1,4	0,353	0,9	0,121	0,6	0,039	0,4	0,017	0,3	0,007	0,2	0,003	0,1				
0,60					4,964	2,8	1,486	1,7	0,491	1,1	0,168	0,7	0,054	0,4	0,023	0,3	0,010	0,2	0,004	0,1				
0,70					6,616	3,2	1,972	2,0	0,649	1,3	0,221	0,8	0,071	0,5	0,031	0,4	0,013	0,2	0,005	0,2				
0,80							2,523	2,3	0,828	1,4	0,281	0,9	0,090	0,6	0,039	0,4	0,016	0,3	0,006	0,2	0,003	0,2		
0,90							3,138	2,5	1,027	1,6	0,348	1,0	0,111	0,6	0,048	0,5	0,020	0,3	0,008	0,2	0,004	0,2		
1,00							3,816	2,8	1,245	1,8	0,421	1,2	0,135	0,7	0,058	0,5	0,024	0,4	0,009	0,2	0,005	0,2		
1,20							5,364	3,4	1,742	2,2	0,587	1,4	0,187	0,9	0,080	0,6	0,033	0,4	0,013	0,3	0,007	0,2		
1,40									2,317	2,5	0,778	1,6	0,247	1,0	0,106	0,7	0,044	0,5	0,017	0,3	0,009	0,3		
1,60									2,971	2,9	0,994	1,8	0,315	1,2	0,135	0,8	0,056	0,6	0,021	0,4	0,011	0,3		
1,80									3,702	3,2	1,235	2,1	0,390	1,3	0,167	0,9	0,069	0,6	0,026	0,4	0,014	0,3		
2,00											1,501	2,3	0,473	1,4	0,202	1,0	0,083	0,7	0,032	0,5	0,017	0,4		
2,20											1,791	2,5	0,563	1,6	0,240	1,1	0,099	0,8	0,038	0,5	0,019	0,4		
2,40											2,106	2,8	0,660	1,7	0,281	1,2	0,116	0,8	0,044	0,6	0,023	0,4		
2,60											2,445	3,0	0,765	1,9	0,325	1,3	0,134	0,9	0,051	0,6	0,027	0,5		
2,80											2,809	3,2	0,877	2,0	0,373	1,4	0,153	1,0	0,058	0,7	0,030	0,5		
3,00											3,197	3,5	0,996	2,2	0,423	1,5	0,174	1,1	0,066	0,7	0,035	0,6		
3,20													1,123	2,3	0,476	1,6	0,195	1,1	0,074	0,8	0,039	0,6		
3,40													1,256	2,5	0,532	1,7	0,218	1,2	0,083	0,8	0,043	0,6		
3,60													1,397	2,6	0,591	1,8	0,242	1,3	0,092	0,9	0,048	0,7		
3,80													1,545	2,7	0,653	1,9	0,267	1,3	0,101	0,9	0,054	0,7		
4,00													1,701	2,9	0,718	2,0	0,293	1,4	0,111	1,0	0,058	0,7		
4,20													1,863	3,0	0,786	2,1	0,321	1,5	0,121	1,0	0,064	0,8		
4,40													2,033	3,2	0,856	2,2	0,349	1,6	0,132	1,0	0,070	0,8		
4,60													2,210	3,3	0,930	2,3	0,379	1,6	0,143	1,1	0,075	0,8		
4,80													2,394	3,5	1,006	2,4	0,410	1,7	0,155	1,1	0,081	0,9		
5,00															1,086	2,5	0,442	1,8	0,167	1,2	0,088	0,9		
5,20																1,158	2,7	0,470	1,8	0,175	1,2	0,093	1,0	
5,40																	1,242	2,8	0,504	1,9	0,188	1,3	0,101	1,0
5,60																	1,327	2,8	0,539	2,0	0,199	1,3	0,108	1,0
5,80																	1,416	2,9	0,575	2,1	0,214	1,4	0,114	1,1
6,00																	1,517	3,1	0,612	2,1	0,228	1,4	0,122	1,1
6,20																		0,651	2,2	0,243	1,5	0,128	1,1	
6,40																		0,690	2,3	0,256	1,5	0,137	1,2	
6,60																		0,730	2,3	0,272	1,6	0,146	1,2	
6,80																		0,778	2,4	0,288	1,6	0,152	1,2	
7,00																		0,821	2,5	0,301	1,7	0,162	1,3	

PPR S 2,5 (PN20) water temperature = 80° C

k=0,01	16 x 2,7 mm		20 x 3,4 mm		25 x 4,2 mm		32 x 5,4 mm		40 x 6,7 mm		50 x 8,4 mm		63 x 10,5 mm		75 x 12,5 mm		90 x 15,0 mm		110 x 18,4 mm		125 x 20,8 mm			
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s												
0,02	0,087	0,2	0,030	1,1	0,010	0,1	0,003	0,1																
0,04	0,299	0,5	0,104	0,3	0,035	0,2	0,011	0,1	0,004	0,1														
0,06	0,619	0,7	0,214	0,4	0,071	0,3	0,022	0,2	0,007	0,1	0,003	0,1												
0,08	1,042	0,9	0,359	0,6	0,119	0,4	0,037	0,2	0,012	0,1	0,004	0,1	0,001	0,1										
0,10	1,565	1,1	0,536	0,7	0,177	0,5	0,054	0,3	0,018	0,2	0,006	0,1	0,002	0,1	0,001	0,1								
0,12	2,186	1,4	0,746	0,9	0,245	0,6	0,075	0,3	0,025	0,2	0,009	0,1	0,003	0,1	0,001	0,1								
0,14	2,905	1,6	0,988	1,0	0,323	0,6	0,099	0,4	0,033	0,3	0,012	0,2	0,004	0,1	0,002	0,1	0,001	0,0						
0,16	3,719	1,8	1,261	1,2	0,412	0,7	0,126	0,5	0,042	0,3	0,015	0,2	0,005	0,1	0,002	0,1	0,001	0,1						
0,18	4,630	2,0	1,565	1,3	0,510	0,8	0,155	0,5	0,052	0,3	0,018	0,2	0,006	0,1	0,003	0,1	0,001	0,1						
0,20	5,636	2,3	1,900	1,5	0,617	0,9	0,188	0,6	0,063	0,4	0,022	0,2	0,007	0,1	0,003	0,1	0,001	0,1						
0,30	12,090	3,4	4,031	2,2	1,296	1,4	0,391	0,8	0,130	0,5	0,045	0,3	0,014	0,2	0,006	0,2	0,003	0,1	0,001	0,1				
0,40		6,918	2,9	2,206	1,8	0,661	1,1	0,218	0,7	0,075	0,5	0,024	0,3	0,010	0,2	0,004	0,1	0,002	0,1					
0,50				3,346	2,3	0,995	1,4	0,327	0,9	0,111	0,6	0,036	0,4	0,015	0,3	0,006	0,2	0,002	0,1					
0,60					4,712	2,8	1,395	1,7	0,456	1,1	0,155	0,7	0,050	0,4	0,021	0,3	0,009	0,2	0,003	0,1				
0,70						6,304	3,2	1,858	2,0	0,605	1,3	0,205	0,8	0,065	0,5	0,028	0,4	0,012	0,2	0,005	0,2			
0,80							2,384	2,3	0,774	1,4	0,261	0,9	0,083	0,6	0,036	0,4	0,015	0,3	0,006	0,2	0,003	0,2		
0,90							2,974	2,5	0,963	1,6	0,324	1,0	0,103	0,6	0,044	0,5	0,018	0,3	0,007	0,2	0,003	0,2		
1,00							3,626	2,8	1,171	1,8	0,392	1,2	0,124	0,7	0,053	0,5	0,022	0,4	0,009	0,2	0,004	0,2		
1,20							5,121	3,4	1,645	2,2	0,549	1,4	0,173	0,9	0,074	0,6	0,031	0,4	0,012	0,3	0,006	0,2		
1,40								2,197	2,5	0,730	1,6	0,230	1,0	0,098	0,7	0,040	0,5	0,016	0,3	0,008	0,3			
1,60								2,826	2,9	0,936	1,8	0,293	1,2	0,125	0,8	0,051	0,6	0,020	0,4	0,010	0,3			
1,80								3,532	3,2	1,166	2,1	0,364	1,3	0,155	0,9	0,064	0,6	0,024	0,4	0,012	0,3			
2,00									1,421	2,3	0,443	1,4	0,188	1,0	0,077	0,7	0,029	0,5	0,015	0,4				
2,20									1,700	2,5	0,528	1,6	0,224	1,1	0,092	0,8	0,035	0,5	0,018	0,4				
2,40									2,003	2,8	0,621	1,7	0,263	1,2	0,107	0,8	0,041	0,6	0,021	0,4				
2,60									2,331	3,0	0,721	1,9	0,304	1,3	0,124	0,9	0,047	0,6	0,024	0,5				
2,80									2,682	3,2	0,828	2,0	0,349	1,4	0,142	1,0	0,054	0,7	0,027	0,5				
3,00									3,058	3,5	0,942	2,2	0,397	1,5	0,162	1,1	0,061	0,7	0,031	0,6				
3,20										1,064	2,3	0,447	1,6	0,182	1,1	0,069	0,8	0,036	0,6					
3,40										1,192	2,5	0,501	1,7	0,204	1,2	0,077	0,8	0,039	0,6					
3,60										1,328	2,6	0,557	1,8	0,226	1,3	0,085	0,9	0,044	0,7					
3,80										1,471	2,7	0,616	1,9	0,250	1,3	0,094	0,9	0,049	0,7					
4,00										1,621	2,9	0,679	2,0	0,275	1,4	0,103	1,0	0,053	0,7					
4,20										1,778	3,0	0,744	2,1	0,301	1,5	0,113	1,0	0,058	0,8					
4,40										1,942	3,2	0,812	2,2	0,328	1,6	0,123	1,0	0,064	0,8					
4,60										2,113	3,3	0,882	2,3	0,356	1,6	0,134	1,1	0,068	0,8					
4,80										2,292	3,5	0,956	2,4	0,386	1,7	0,145	1,1	0,074	0,9					
5,00											1,033	2,5	0,416	1,8	0,156	1,2	0,081	0,9						
5,20											1,081	2,7	0,436	1,8	0,161	1,2	0,085	1,0						
5,40											1,160	2,8	0,467	1,9	0,173	1,3	0,092	1,0						
5,60											1,242	2,9	0,500	2,0	0,184	1,3	0,099	1,0						
5,80											1,326	3,0	0,534	2,1	0,199	1,4	0,105	1,1						
6,00											1,422	3,1	0,569	2,1	0,210	1,4	0,112	1,1						
6,20												0,605	2,2	0,224	1,5	0,118	1,1							
6,40												0,642	2,3	0,236	1,5	0,126	1,2							
6,60												0,680	2,3	0,251	1,6	0,134	1,2							
6,80												0,725	2,4	0,266	1,6	0,140	1,2							
7,00												0,765	2,5	0,279	1,7	0,149	1,3							

Pressure Loss Tables

FIBER BASALT PLUS, STABI PLUS S 4, S 3,2 water temperature = 10° C

EVO, PP-RCT S 3,2, S 4 water temperature = 10 °C

k=0,01			20 x 2,3 mm		25 x 2,8 mm		32 x 3,6 mm		40 x 4,5 mm		50 x 5,6 mm		63 x7,1 mm		75 x 8,4 mm		90 x 10,1 mm		110 x 12,3 mm		125 x 14 mm	
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s
0,02	0,068	0,2	0,020	0,1																		
0,04	0,230	0,4	0,067	0,2	0,016	0,1	0,006	0,1														
0,06	0,473	0,6	0,137	0,3	0,033	0,2	0,008	0,1	0,004	0,1												
0,08	0,792	0,8	0,227	0,4	0,076	0,3	0,019	0,2	0,006	0,1												
0,10	1,306	1,0	0,337	0,5	0,113	0,3	0,036	0,2	0,009	0,1	0,002	0,1										
0,20	4,420	1,9	1,150	1,1	0,377	0,7	0,114	0,4	0,039	0,3	0,014	0,2	0,005	0,1	0,002	0,1						
0,30	9,208	2,8	2,370	1,6	0,757	1,0	0,235	0,6	0,082	0,4	0,027	0,3	0,009	0,2	0,004	0,1						
0,40																						
0,50																						
0,60																						
0,70																						
0,80																						
0,90																						
1,00																						
1,20																						
1,40																						
1,60																						
1,80																						
2,00																						
2,20																						
2,40																						
2,60																						
2,80																						
3,00																						
3,20																						
3,40																						
3,60																						
3,80																						
4,00																						
4,20																						
4,40																						
4,60																						
4,80																						
5,00																						
5,20																						
5,40																						
5,60																						
5,80																						
6,00																						
6,20																						
6,40																						
6,60																						
6,80																						
7,00																						
7,50																						
8,00																						
8,50																						
9,00																						
9,50																						
10,0																						
10,5																						
11,0																						
11,5																						
12,0																						
12,5																						
13,0																						
13,5																						
14,0																						
15,5																						
15,0																						
15,5																						
16,0																						
16,5																						
17,0																						
17,5																						
18,0																						
18,5																						
19,0																						
19,5																						
20,0																						
20,5																						

Pressure Loss Tables

EVO, PP-RCT S 4, S 5 water temperature = 50 °C

k=0,01	16 x 2,2 mm	20 x 2,3 mm	25 x 2,8 mm	32 x 3,6 mm	40 x 4,5 mm	50 x 5,6 mm	63 x 7,1 mm	75 x 8,4 mm	90 x 10,1 mm	110 x 12,3 mm	125 x 14 mm
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m						
0,02	0,068	0,2	0,013	0,1							
0,04	0,230	0,4	0,052	0,2	0,019	0,1	0,003	0,1			
0,06	0,473	0,6	0,108	0,3	0,035	0,2	0,009	0,1	0,003	0,1	
0,08	0,792	0,8	0,181	0,4	0,060	0,3	0,015	0,2	0,006	0,1	0,002
0,10	1,064	1,0	0,271	0,5	0,089	0,3	0,028	0,2	0,009	0,1	0,003
0,20	3,723	1,9	0,925	1,1	0,306	0,7	0,091	0,4	0,031	0,3	0,017
0,30	7,920	2,8	1,947	1,6	0,624	1,0	0,191	0,6	0,066	0,4	0,022
0,40			3,319	2,2	1,059	1,4	0,323	0,8	0,109	0,5	0,037
0,50			4,999	2,7	1,599	1,7	0,486	1,0	0,162	0,7	0,055
0,60			7,046	3,2	2,242	2,0	0,669	1,2	0,224	0,8	0,077
0,70					2,289	2,4	0,891	1,5	0,301	0,9	0,100
0,80					3,837	2,7	1,143	1,7	0,382	1,1	0,129
0,90					4,757	3,0	1,409	1,9	0,471	1,2	0,158
1,00					5,805	3,4	1,718	2,1	0,570	1,3	0,194
1,20							1,366	2,1	0,451	1,4	0,150
1,40							1,694	2,4	0,561	1,5	0,183
1,60							2,071	2,7	0,682	1,7	0,223
1,80							2,467	2,9	0,815	1,9	0,266
2,00							2,915	3,2	0,958	2,0	0,309
2,20									1,113	2,2	0,360
2,40									1,455	2,5	0,467
2,60									1,643	2,7	0,528
2,80									1,841	2,9	0,592
3,00										1,455	1,9
3,20										1,643	2,7
3,40										1,841	2,9
3,60											0,654
3,80											0,725
4,00											0,800
4,20											0,878
4,40											0,953
4,60											1,038
4,80											1,126
5,00											1,210
5,20											1,305
5,40											1,403
5,60											1,496
5,80											
6,00											
6,20											
6,40											
6,60											
6,80											
7,00											
7,50											
8,00											
8,50											
9,00											
9,50											
10,0											
10,5											
11,0											
11,5											
12,0											
12,5											
13,0											
13,5											
14,0											
14,5											
15,0											
15,5											
16,0											
16,5											
17,0											
17,5											
18,0											
18,5											
19,0											
19,5											
20,0											
20,5											

EVO, PP-RCT S 4, S 5 water temperature = 80 °C

k=0,01	16 x 2,2 mm	20 x 2,3 mm	25 x 2,8 mm	32 x 3,6 mm	40 x 4,5 mm	50 x 5,6 mm	63 x7,1 mm	75 x 8,4 mm	90 x 10,1 mm	110 x 12,3 mm	125 x 14 mm
Q l/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m
0,02	0,055	0,2									
0,04	0,185	0,4									
0,06	0,381	0,6			0,003	0,1					
0,08	0,641	0,8			0,006	0,1					
0,10	0,962	1,0	0,242	0,5	0,079	0,3	0,025	0,2	0,008	0,1	0,003
0,20	3,428	1,9	0,840	1,1	0,275	0,7	0,081	0,4	0,027	0,3	0,010
0,30	7,376	2,8	1,788	1,6	0,567	1,0	0,172	0,6	0,059	0,4	0,019
0,40			3,070	2,2	0,969	1,4	0,292	0,8	0,098	0,5	0,033
0,50			4,652	2,7	1,471	1,7	0,442	1,0	0,146	0,7	0,049
0,60			6,590	3,2	2,073	2,0	0,612	1,2	0,203	0,8	0,069
0,70					2,774	2,4	0,818	1,5	0,274	0,9	0,090
0,80					3,574	2,7	1,052	1,7	0,348	1,1	0,117
0,90					1,445	3,0	1,301	1,9	0,431	1,2	0,143
1,00					1,591	2,1	0,522	1,3	0,176	0,9	0,056
1,20					2,236	2,5	0,739	1,6	0,242	1,0	0,079
1,40					3,008	2,9	0,981	1,9	0,323	1,2	0,106
1,60							1,267	2,1	0,414	1,4	0,136
1,80							1,576	2,4	0,517	1,5	0,167
2,00							1,931	2,7	0,630	1,7	0,204
2,20							2,306	2,9	0,754	1,9	0,244
2,40							2,73	3,2	0,888	2,0	0,284
2,60									1,034	2,2	0,331
2,80									1,190	2,4	0,381
3,00									1,356	2,5	0,430
3,20									1,534	2,7	0,487
3,40									1,721	2,9	0,548
3,60											0,606
3,80											0,673
4,00											0,743
4,20											0,817
4,40											0,887
4,60											0,967
4,80											1,051
5,00											1,130
5,20											1,220
5,40											1,313
5,60											1,401
5,80											1,622
6,00											0,666
6,50											0,770
7,00											0,888
7,50											1,013
8,00											1,147
8,50											0,517
9,00											0,576
9,50											0,638
10,0											0,703
10,5											0,771
11,0											0,842
11,5											0,922
12,0											
12,5											
13,0											
13,5											
14,0											
14,5											
15,0											
15,5											
16,0											
16,5											
17,0											
17,5											
18,0											
18,5											
19,0											
19,5											
20,0											
20,5											
21,0											
21,5											
22,0											

System Ekoplastik

Wavin Ekoplastik System diameters 160-250 mm

The system consists of monolayer pipes, multilayer pipes and fittings with diameters between 160-250 mm and is manufactured from the PP-RCT material. The system is intended for pressure distribution systems of potable (cold) water, hot water, compressed air, cooling water and air conditioning. The system is compatible with butt welding techniques.

- ⌚ Estimated delivery time for the listed product range is 30 days.
- ⌚ Standard products (I) are covered by a 10-year warranty period.
- ⌚ Other products (IV.) are covered by a 2-year warranty period.



Benefits

- ⌚ Pipes and fittings made from PP-RCT (type 4), new generation polypropylene material
- ⌚ Pipes and fittings of larger diameters than 125 mm are designed for butt welding
- ⌚ Same flow profile for both fittings and monolayer pipes – minimal pressure losses

Technical information:

All required technical information is listed in the Wavin Ekoplastik System installation manual.

The technical information not included in the Wavin Ekoplastik System installation manual is listed below.

Linear expansion of Ekoplastik – monolayer pipes

$$\Delta l = \alpha \cdot L \cdot \Delta t [mm]$$

Δl - linear change [mm]

α - thermal expansion coefficient [mm/m °C]


for monolayer plastic pipes $\alpha = 0,12$

for multilayer pipes $\alpha = 0,05$

L - effective length (distance between two neighbouring fixed points in line) [m]

Δt - installation and service temperature difference [°C]

Effective pipe length L



Δl - linear change (mm)


Pipe length	Temperature difference Δt					
	10 °C	20 °C	30 °C	40 °C	50 °C	60 °C
	Linear change Δl [mm]					
1 m	1	2	4	5	6	7
2 m	2	5	7	10	12	14
3 m	4	7	11	14	18	22
4 m	5	10	14	19	24	29
5 m	6	12	18	24	30	36
6 m	7	14	22	29	36	43
7 m	8	17	25	34	42	50
8 m	10	19	29	38	48	58
9 m	11	22	32	43	54	65
10 m	12	24	36	48	60	72
15 m	18	36	54	72	90	108

System Ekoplastik

Technical information:

Linear expansion of Ekoplastik - multilayer pipe

Effective pipe length L



Δl - linear change (mm)

Pipe length	Temperature difference Δt					
	10 °C	20 °C	30 °C	40 °C	50 °C	60 °C
	Linear change Δl [mm]					
1 m	1	1	2	2	3	3
2 m	1	2	3	4	5	6
3 m	2	3	5	6	8	9
4 m	2	4	6	8	10	12
5 m	3	5	8	10	13	15
6 m	3	6	9	12	15	18
7 m	4	7	11	14	18	21
8 m	4	8	12	16	20	24
9 m	5	9	14	18	23	27
10 m	5	10	15	20	25	30
15 m	8	15	23	30	38	45

Determination of L_s – compensating length


$$L_s = k \cdot \sqrt{D \cdot \Delta l} \text{ [mm]}$$

L_s - compensating length [mm]

k - material constant, for PPR k = 20

D - external diameter of the pipe [mm]

Δl - linear change [mm]



Δl - linear change [mm]

Pipe diameter [mm]	Linear charge Δl [mm]									
	10	20	30	40	50	60	70	80	90	100
	Compensating length L_s [m]									
160	0,80	1,13	1,39	1,60	1,79	1,96	2,12	2,26	2,40	2,53
200	0,89	1,26	1,55	1,79	2,00	2,19	2,37	2,53	2,68	2,83
250	1,00	1,41	1,73	2,00	2,24	2,45	2,65	2,83	3,00	3,16

Spacing distance between pipe supports

Pipe diameter [mm]	spacing distances in [cm] at temperature of				
	20 °C	30 °C	40 °C	50 °C	60 °C
160	220	210	200	195	185
200	245	235	225	220	210
250	275	265	250	245	235

System Ekoplastik

Working the pipe

Butt welding process

We recommend using a special cutter for plastic pipes.

Butt welding is one way of coupling plastic piping systems and its components together. Butt welding is a process in which two pipe ends or a pipe end and a fitting are coupled by pressing the melted contact surfaces together. Butt welding can be performed only with welding equipment specifically designed for such purpose and only by appropriately qualified staff.

Butt welding is not suitable for coupling pipes and fittings of different size (the diameter and wall thickness must be the same) or different MFI value.

The following text describes the basic welding process. Detailed welding equipment manuals including welding charts are provided by the manufacturer/supplier of the welding equipment.

In order to achieve more solid welds, we recommend using welding machines with hydraulic jaws.

The butt welding procedures described herein are based on DVS 2207.

Butt welding working instructions

Welding preparations

Workplace check

Make sure the workplace meets all the health and safety requirements and take note of dust and weather conditions. During the butt welding process, the ambient temperature must not fall below 5 °C (use a mounting tent if needed). Similar measures must be taken in case of adverse weather conditions (rain, direct sunlight, etc.).

welding process. Ensure the materials you are planning to couple have the same temperature. Butt welding can only be performed with pipes with the same wall thickness (3 mm minimum).

Preparing the materials

Once prepared and properly fastened, cut the pipe perpendicularly to the pipe axis with the tool designated for the purpose. Since the contact surface of the pipe must be clean, dry and free of any oils or fat, avoid using chainsaws with oil chain lubrication. After completing the cut, always make sure to remove any burrs, sawdust or any other impurities created during the pipe cutting process.

Check if the newly created contact surfaces fit well together; a careful inspection can reveal inadequate pipe ovality or tucked ends caused by the manufacturing process. Find out the passive resistance, plane the pipe surfaces as needed, test the fit once again, check for any gaps between the pipes, and finally clean the external surface of the pipes.

Welding equipment check

Check the technical condition of the welding machine (the surface and temperature of the heating plate, alignment of the fixed and movable jaws, milling cutter's functionality etc.).

Materials check

Warning: Check the mutual weldability of the materials before starting the



Planing the pipe ends



Properly prepared for welding



Heating with the heating plate



Cooling the weld seam

Welding phase

Truing phase

Push the contact surfaces against the heating plate until the two contact surfaces line up, which is indicated by the level of burr listed in the welding charts.

Heating phase

The contact surfaces should be heated with minimal contact pressure (see the welding charts for details). Heat up the contact surfaces until the welding zone reaches plastification (see the welding charts for details).

Positioning phase

Slide the contact surfaces away and remove the heating plate. Slide the pipes back as quickly as possible and push them together so their contact surfaces touch.

Coupling phase

When the contact surfaces are touching, raise the contact pressure until you reach full welding pressure.

Cooling phase

During the cooling phase keep the pipes under constant pressure (must be overseen by the welder), until the time allotted for cooling runs out. After the weld is done, perform its visual inspection in accordance with the client's requirements.

Compatibility

In order to ensure proper welding compatibility, pipes and fittings meant for butt welding should not be combined with pipes or fittings produced by a different manufacturer.

Welding parameters

Included with the welding equipment.

Guideline values for polypropylene as specified in DVS 2207 - Part 11:

Hot body temperature: 200–220 °C

Welding pressure:

⌚ Truing and coupling: 0.10 N/mm²

⌚ Heating: 0.01 N/mm²

Welding time: divided according to the phases - see the chart below.

1	2	3	4	5	
Nominal wall thickness	Truing	Heating	Positioning	Coupling	
	Hot body temperature: 210 +/- 10 °C		Positioning period (max.)	Coupling pressure rise period	Cooling under coupling pressure period (min. values) $p = 0.10 \text{ N/mm}^2 +/- 0.01$
	Burr level on the hot body after truing period (min. values)	(heating p. = $\leq 0.01 \text{ N/mm}^2$)			
	(truing p. = 0.10 N/mm^2)				
[mm]	[mm]	[s]	[s]	[s]	[min]
up to 4,5	0,5	up to 135	5	6	6
4,5 - 7	0,5	135 - 175	5 - 6	6 - 7	6 - 12
7 - 12	1,0	175 - 245	6 - 7	7 - 11	12 - 20
12 - 19	1,0	245 - 330	7 - 9	11 - 17	20 - 30
19 - 26	1,5	330 - 400	9 - 11	17 - 22	30 - 40
26 - 37	2,0	400 - 485	11 - 14	22 - 32	40 - 55
27 - 50	2,0	485 - 560	14 - 17	32 - 43	55 - 70

System Ekoplastik

Flange connections

Installation of flanged connections

During the process of designing flanged connections there should be taken into account the following conditions (When planning flanged connections, the following conditions should be taken into account):

In general, it is necessary to distinguish a classic flange connecting (connection) of two plastic pipes from a flanged connection, where the edge adapter (collar) constitutes a junction piece between a plastic pipe and a different material – usually a metal pipe or a shut-off valve (fitting). Hence, in each case it is necessary to choose a right seal and a suitable flange. The flanges to be used should possess a sufficient thermal and mechanical stability. The Georg Fischer Wavin flanges match all the above-mentioned requirements.

Axial flange setting.

In horizontally mounted pipelines, flanges must be affixed (bolted) as it is shown in the illustration hereto in order to prevent possible leakage of the transferred medium through bolt threads.



Note:

It is impossible to use flange connections for elastic and / or compensatory structures, because in this case, they will be under the bend load that can break the hermetic proofing of flanged connections. The adapter (collar), flange, and the sealing gasket should be aligned exactly by the pipeline axel. When installing gaskets between flanges, make sure to check whether the seal dimensions match the inner and outer flange adapter (collar). If the difference between the internal gasket diameter and the collar exceeds 10 mm, issues with the connection may occur.

Before final tightening of the bolts, the surfaces to be connected must be aligned and precisely settled on the sealing gasket. Any tension on a pipe with flange connections is unacceptable due to the emerging tension load. The bolt length must be chosen so that its thread does exceed the flange (rise over the flange) by two or free turns of the entire thread. It is necessary to put the washer under the head of the bolt and under the nut.

In order to easily remove the bolts even after long-term use, their threads should be lubricated (e.g. molybdenum sulfide based lubricant). The bolts are tightened diagonally with a smooth transfer of power, and the nuts must be first tightened manually, so that the gasket will sit exactly in place and the distance between adapters (shoulders) is minimal. Afterwards the bolts will be cross-tightened at recommended 50% of the tightening torque, and just after this on at total 100% of the tightening torque.

Later it is recommended to check flange connections within 24 hours after the installation and, if necessary, to tighten them up again. More connection checks are required after pressure tests; tighten them once more if necessary. For more detailed information on flange connections, please refer to DVS 2210-1, Annex No. 3.

Bolt tightening torque

Bolt tightening torque in flange connections is particularly important. In practice, several methods exist:

1. Tighten the bolts as much as possible. However, in time it may turn out that the connection is too tight and excessive pressure is created in plastic pipes.
2. Tighten the bolts by “eyeballing” it. This method requires considerable experience and knowledge of the material.
3. With a torque wrench – generally the best and most reliable method.

Recommended values are listed in the table. In practice, slight deviations from table values are allowed. This can be caused, for example, by using self-locking nuts or by an insufficiently aligned axis of the pipeline. The hardness of the gasket (according to Shore) may also affect the required tightening torque (consult the information on gasket materials for more details).

Values of tightening torques for metric flange connections (ISO) with steel flanges PP-V and PP-stee

Pipe diameter d [mm]	Rated diameter DN	Flat gasket	Shaped gasket	Wiper seal
		Maximum pressure 10 bar / 40 °C	Maximum pressure 10 bar	Maximum pressure 10 bar
160, 180	150	60	35	30
200, 225	200	10 ¹⁾	45	35
250, 280	250	65 ¹⁾	35	30

¹⁾ Up to the maximum operating pressure of 6 bar

PP-V flanges

PP-V flanges possess following the properties:

- ➊ PP polypropylene anti-corrosive support flange (30% reinforced fiberglass)
- ➋ high chemical resistance (including against hydrolysis)
- ➌ Maximum breaking strength (deformations occur when locking)


Temperature resistance to up to 80°C

Note

The temperature of the medium is limited by the plastic pipes system material i.e. ABS, PVCU, PVC-C, PP, PE

Weld-in saddles

- ① A wide range of profiled fittings allows you to attach a branch pipe with a diameter of 32, 40 mm
- ② For all Ekoplastik pipeline series with diameters of 160, 200 and 250 mm
- ③ The principle of polyfusion type C welding has been preserved.
- ④ For each pipe diameter there are particular heating extension pieces, which are universally compatible with all types of flat welding machines
- ⑤ Using weld-in saddles saves time and space and it replaces T-fittings and reducer couplings / increasers.
- ⑥ A perfect weld seam is achieved by connecting a saddle and pipe over the entire welding area.



① Using a special drill (the table on the left), drill a hole for the pipe.



② Clean the hole, degrease the fitting and drill a hole.



③ Mount the weld-in saddle on the heating extension piece and align the saddle and the extension piece guidng marks. Heat up the hole and the weld-in saddle.




④ Install the heated up saddle in the heated hole and affix them there. After an hour, you can fill the system with water and expose it to the proper pressure.

Saddle sizes [mm]	Drill diameters [mm]
160 × 40	38
160 × 50	47
160 × 63	60
200 × 50	47
200 × 63	60
200 × 75	75
200 × 90	88
250 × 63	60
250 × 75	75
250 × 90	88
250 × 110	110

Saddle sizes [mm]	Heating time [sec.]	Fixation time [sec.]
160 × 40	12	20
160 × 50	18	20
160 × 63	24	30
200 × 50	18	20
200 × 63	24	30
200 × 75	30	30
200 × 90	40	40
250 × 63	24	30
250 × 75	30	30
250 × 90	40	40
250 × 110	50	50

Pressure Loss Tables

Isothermal lines for PP-RCT mechanical strength



Termination of the isotherm indicates maximum service life even at lower tensions. The isotherms depicted in the chart are not extended.

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q	R	v	R	v	R	v
1/s	kPa/m	m/s	kPa/m	m/s	kPa/m	m/s
1,40	0,001	0,1				
1,60	0,002	0,1				
1,80	0,002	0,1				
2,00	0,002	0,2				
2,20	0,003	0,2				
2,40	0,003	0,2				
2,60	0,004	0,2				
2,80	0,004	0,2	0,001	0,1		
3,00	0,005	0,2	0,002	0,1		
3,20	0,006	0,2	0,002	0,2		
3,40	0,006	0,3	0,002	0,2		
3,60	0,007	0,3	0,002	0,2		
3,80	0,007	0,3	0,003	0,2		
4,00	0,008	0,3	0,003	0,2		
4,20	0,009	0,3	0,003	0,2		
4,40	0,010	0,3	0,003	0,2		
4,60	0,010	0,3	0,004	0,2	0,001	0,1
4,80	0,011	0,4	0,004	0,2	0,001	0,2
5,00	0,012	0,4	0,004	0,2	0,001	0,2
5,20	0,013	0,4	0,005	0,3	0,002	0,2
5,40	0,014	0,4	0,005	0,3	0,002	0,2
5,60	0,015	0,4	0,005	0,3	0,002	0,2
5,80	0,016	0,4	0,006	0,3	0,002	0,2
6,00	0,017	0,5	0,006	0,3	0,002	0,2
6,20	0,017	0,5	0,006	0,3	0,002	0,2
6,40	0,019	0,5	0,006	0,3	0,002	0,2
6,60	0,020	0,5	0,007	0,3	0,002	0,2
6,80	0,021	0,5	0,007	0,3	0,003	0,2
7,00	0,022	0,5	0,007	0,3	0,003	0,2
7,5	0,025	0,6	0,009	0,4	0,003	0,2
8	0,028	0,6	0,009	0,4	0,003	0,2
8,5	0,031	0,6	0,010	0,4	0,004	0,3
9	0,034	0,7	0,012	0,4	0,004	0,3
9,5	0,040	0,7	0,013	0,5	0,004	0,3
10	0,041	0,7	0,014	0,5	0,005	0,3
10,5	0,045	0,8	0,015	0,5	0,005	0,3
11	0,049	0,8	0,017	0,5	0,006	0,3
11,5	0,054	0,9	0,018	0,6	0,006	0,4
12	0,057	0,9	0,020	0,6	0,007	0,4
12,5	0,062	0,9	0,021	0,6	0,007	0,4
13	0,067	1	0,023	0,6	0,008	0,4
13,5	0,070	1	0,024	0,6	0,008	0,4
14	0,076	1	0,026	0,7	0,009	0,4
14,5	0,081	1,1	0,028	0,7	0,009	0,4
15	0,086	1,1	0,029	0,7	0,010	0,5
15,5	0,091	1,2	0,031	0,7	0,011	0,5
16	0,096	1,2	0,033	0,8	0,011	0,5
16,5	0,102	1,2	0,034	0,8	0,012	0,5
17	0,109	1,3	0,037	0,8	0,013	0,5

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q	R	v	R	v	R	v
1/s	kPa/m	m/s	kPa/m	m/s	kPa/m	m/s
17,5	0,113	1,3	0,038	0,8	0,013	0,5
18	0,120	1,3	0,041	0,9	0,014	0,6
18,5	0,126	1,4	0,043	0,9	0,014	0,6
19	0,131	1,4	0,044	0,9	0,015	0,6
19,5	0,138	1,5	0,047	0,9	0,016	0,6
20	0,145	1,5	0,049	1,0	0,017	0,6
20,5	0,152	1,5	0,052	1,0	0,017	0,6
21	0,158	1,6	0,054	1,0	0,018	0,6
21,5	0,165	1,6	0,056	1,0	0,019	0,7
22	0,173	1,6	0,059	1,1	0,020	0,7
22,5	0,179	1,7	0,061	1,1	0,020	0,7
23	0,187	1,7	0,063	1,1	0,022	0,7
23,5	0,195	1,8	0,066	1,1	0,022	0,7
24	0,203	1,8	0,068	1,1	0,023	0,7
24,5	0,209	1,8	0,071	1,2	0,024	0,8
25	0,218	1,9	0,074	1,2	0,025	0,8
25,5	0,226	1,9	0,076	1,2	0,026	0,8
26	0,233	1,9	0,079	1,2	0,027	0,8
26,5	0,242	2	0,082	1,3	0,028	0,8
27	0,251	2	0,084	1,3	0,029	0,8
27,5	0,260	2,1	0,088	1,3	0,030	0,8
28	0,267	2,1	0,090	1,3	0,031	0,9
28,5	0,276	2,1	0,094	1,4	0,032	0,9
29	0,286	2,2	0,096	1,4	0,033	0,9
29,5	0,296	2,2	0,099	1,4	0,034	0,9
30	0,303	2,2	0,103	1,4	0,035	0,9
30,5	0,313	2,3	0,105	1,5	0,036	0,9
31	0,324	2,3	0,108	1,5	0,037	0,9
31,5	0,331	2,3	0,112	1,5	0,038	0,9
32	0,342	2,4	0,115	1,5	0,039	1
32,5	0,352	2,4	0,119	1,6	0,040	1
33			0,122	1,6	0,041	1
33,5			0,125	1,6	0,043	1
34			0,129	1,6	0,043	1
34,5			0,132	1,6	0,045	1,1
35			0,135	1,7	0,046	1,1
35,5			0,139	1,7	0,047	1,1
36			0,143	1,7	0,048	1,1
36,5			0,147	1,7	0,050	1,1
37			0,150	1,8	0,051	1,1
37,5			0,153	1,8	0,052	1,1
38			0,158	1,8	0,054	1,2
38,5			0,161	1,8	0,055	1,2
39			0,166	1,9	0,056	1,2
39,5			0,170	1,9	0,057	1,2
40			0,173	1,9	0,059	1,2
40,5			0,178	1,9	0,060	1,2
41			0,181	2,0	0,062	1,3
41,5			0,185	2,0	0,062	1,3

Pressure Loss Tables

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q 1/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s
42			0,190	2,0	0,064	1,3
42,5			0,193	2,0	0,065	1,3
43			0,199	2,1	0,067	1,3
43,5			0,202	2,1	0,068	1,3
44			0,206	2,1	0,070	1,3
44,5			0,211	2,1	0,071	1,4
45			0,215	2,1	0,073	1,4
45,5			0,219	2,2	0,074	1,4
46			0,224	2,2	0,076	1,4
46,5			0,228	2,2	0,077	1,4
47			0,234	2,2	0,079	1,4
47,5			0,238	2,3	0,080	1,4
48			0,242	2,3	0,082	1,5
48,5			0,247	2,3	0,084	1,5
49			0,251	2,3	0,085	1,5
49,5			0,255	2,4	0,087	1,5
50			0,261	2,4	0,088	1,5
50,5			0,265	2,4	0,090	1,5
51			0,272	2,4	0,091	1,6
51,5			0,276	2,5	0,093	1,6
52					0,094	1,6
52,5					0,097	1,6
53					0,098	1,6
53,5					0,100	1,6
54					0,101	1,6
54,5					0,103	1,7
55					0,104	1,7
55,5					0,107	1,7
56					0,108	1,7
56,5					0,110	1,7
57					0,111	1,7
57,5					0,114	1,8
58					0,115	1,8
58,5					0,117	1,8
59					0,119	1,8
59,5					0,121	1,8
60					0,122	1,8
60,5					0,125	1,8
61					0,127	1,9

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q 1/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s
61,5					0,128	1,9
62					0,131	1,9
62,5					0,132	1,9
63					0,135	1,9
63,5					0,136	1,9
64					0,139	2,0
64,5					0,140	2,0
65					0,143	2,0
65,5					0,144	2,0
66					0,147	2,0
66,5					0,148	2,0
67					0,151	2,0
67,5					0,152	2,1
68					0,155	2,1
68,5					0,156	2,1
69					0,159	2,1
69,5					0,160	2,1
70					0,163	2,1
70,5					0,165	2,1
71					0,167	2,2
71,5					0,169	2,2
72					0,172	2,2
72,5					0,175	2,2
73					0,176	2,2
73,5					0,179	2,2
74					0,180	2,3
74,5					0,183	2,3
75					0,185	2,3
75,5					0,188	2,3
76					0,189	2,3
76,5					0,192	2,3
77					0,194	2,3
77,5					0,197	2,4
78					0,199	2,4
78,5					0,202	2,4
79					0,203	2,4
79,5					0,206	2,4
80					0,208	2,4
80,5					0,211	2,5

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160×14,6		200×18,2		250×22,7	
	Q	R	v	R	v	R
	1/s	kPa/m	m/s	kPa/m	m/s	kPa/m
1,40	0,001	0,1				
1,60	0,001	0,1				
1,80	0,002	0,1				
2,00	0,002	0,2				
2,20	0,002	0,2				
2,40	0,003	0,2				
2,60	0,003	0,2				
2,80	0,004	0,2				
3,00	0,004	0,2	0,001	0,1		
3,20	0,005	0,2	0,002	0,2		
3,40	0,005	0,3	0,002	0,2		
3,60	0,006	0,3	0,002	0,2		
3,80	0,006	0,3	0,002	0,2		
4,00	0,007	0,3	0,002	0,2		
4,20	0,007	0,3	0,003	0,2		
4,40	0,008	0,3	0,003	0,2		
4,60	0,008	0,3	0,003	0,2	0,001	0,1
4,80	0,009	0,4	0,003	0,2	0,001	0,2
5,00	0,010	0,4	0,003	0,2	0,001	0,2
5,20	0,011	0,4	0,004	0,3	0,001	0,2
5,40	0,011	0,4	0,004	0,3	0,001	0,2
5,60	0,012	0,4	0,004	0,3	0,001	0,2
5,80	0,013	0,4	0,005	0,3	0,002	0,2
6,00	0,014	0,5	0,005	0,3	0,002	0,2
6,20	0,015	0,5	0,005	0,3	0,002	0,2
6,40	0,016	0,5	0,005	0,3	0,002	0,2
6,60	0,016	0,5	0,005	0,3	0,002	0,2
6,80	0,017	0,5	0,006	0,3	0,002	0,2
7,00	0,018	0,5	0,006	0,3	0,002	0,2
7,5	0,021	0,6	0,007	0,4	0,002	0,2
8	0,023	0,6	0,008	0,4	0,003	0,2
8,5	0,026	0,6	0,009	0,4	0,003	0,3
9	0,029	0,7	0,010	0,4	0,003	0,3
9,5	0,032	0,7	0,011	0,5	0,004	0,3
10	0,034	0,7	0,012	0,5	0,004	0,3
10,5	0,038	0,8	0,013	0,5	0,004	0,3
11	0,041	0,8	0,014	0,5	0,005	0,3
11,5	0,045	0,9	0,015	0,6	0,005	0,4
12	0,048	0,9	0,016	0,6	0,005	0,4
12,5	0,052	0,9	0,017	0,6	0,006	0,4
13	0,056	1	0,019	0,6	0,007	0,4
13,5	0,060	1	0,020	0,6	0,007	0,4
14	0,064	1	0,022	0,7	0,008	0,4
15,5	0,069	1,1	0,023	0,7	0,008	0,4
15	0,074	1,1	0,024	0,7	0,008	0,5
15,5	0,077	1,2	0,026	0,7	0,009	0,5
16	0,082	1,2	0,028	0,8	0,010	0,5
16,5	0,087	1,2	0,029	0,8	0,010	0,5
17	0,093	1,3	0,031	0,8	0,011	0,5
17,5	0,097	1,3	0,032	0,8	0,011	0,5
18	0,102	1,3	0,035	0,9	0,012	0,6
18,5	0,108	1,4	0,036	0,9	0,012	0,6
19	0,112	1,4	0,038	0,9	0,013	0,6
19,5	0,118	1,5	0,040	0,9	0,013	0,6
20	0,125	1,5	0,042	1,0	0,014	0,6
20,5	0,131	1,5	0,044	1,0	0,015	0,6

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160×14,6		200×18,2		250×22,7	
	Q	R	v	R	v	R
	1/s	kPa/m	m/s	kPa/m	m/s	kPa/m
21	0,136	1,6	0,046	1,0	0,015	0,6
21,5	0,142	1,6	0,047	1,0	0,016	0,7
22	0,149	1,6	0,050	1,1	0,017	0,7
22,5	0,154	1,7	0,052	1,1	0,017	0,7
23	0,161	1,7	0,054	1,1	0,018	0,7
23,5	0,168	1,8	0,056	1,1	0,019	0,7
24	0,175	1,8	0,058	1,1	0,020	0,7
24,5	0,181	1,8	0,061	1,2	0,021	0,8
25	0,188	1,9	0,063	1,2	0,021	0,8
25,5	0,196	1,9	0,065	1,2	0,022	0,8
26	0,202	1,9	0,068	1,2	0,023	0,8
26,5	0,209	2	0,070	1,3	0,024	0,8
27	0,217	2	0,072	1,3	0,024	0,8
27,5	0,226	2,1	0,075	1,3	0,025	0,8
28	0,232	2,1	0,077	1,3	0,026	0,9
28,5	0,240	2,1	0,081	1,4	0,027	0,9
29	0,249	2,2	0,083	1,4	0,028	0,9
29,5	0,257	2,2	0,085	1,4	0,029	0,9
30	0,264	2,2	0,088	1,4	0,029	0,9
30,5	0,273	2,3	0,091	1,5	0,031	0,9
31	0,282	2,3	0,093	1,5	0,031	0,9
31,5	0,289	2,3	0,097	1,5	0,032	1
32	0,298	2,4	0,099	1,5	0,033	1
32,5	0,309	2,4	0,103	1,6	0,034	1
33	0,317	2,5	0,105	1,6	0,035	1
33,5			0,108	1,6	0,036	1
34			0,111	1,6	0,037	1
34,5			0,114	1,6	0,038	1,1
35			0,117	1,7	0,039	1,1
35,5			0,121	1,7	0,040	1,1
36			0,123	1,7	0,041	1,1
36,5			0,127	1,7	0,042	1,1
37			0,130	1,8	0,044	1,1
37,5			0,133	1,8	0,045	1,1
38			0,137	1,8	0,046	1,2
38,5			0,140	1,8	0,047	1,2
39			0,144	1,9	0,048	1,2
39,5			0,147	1,9	0,049	1,2
40			0,150	1,9	0,050	1,2
40,5			0,154	1,9	0,051	1,2
41			0,157	2,0	0,053	1,3
41,5			0,160	2,0	0,054	1,3

Pressure Loss Tables

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q 1/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s
42			0,165	2,0	0,055	1,3
42,5			0,168	2,0	0,056	1,3
43			0,173	2,1	0,058	1,3
43,5			0,176	2,1	0,058	1,3
44			0,179	2,1	0,060	1,3
44,5			0,184	2,1	0,061	1,4
45			0,187	2,1	0,063	1,4
45,5			0,191	2,2	0,063	1,4
46			0,196	2,2	0,065	1,4
46,5			0,199	2,2	0,066	1,4
47			0,204	2,2	0,068	1,4
47,5			0,207	2,3	0,069	1,4
48			0,211	2,3	0,070	1,5
48,5			0,216	2,3	0,072	1,5
49			0,220	2,3	0,073	1,5
49,5			0,223	2,4	0,075	1,5
50			0,229	2,4	0,076	1,5
50,5			0,232	2,4	0,078	1,5
51			0,238	2,4	0,079	1,6
51,5			0,241	2,5	0,081	1,6
52					0,082	1,6
52,5					0,083	1,6
53					0,084	1,6
53,5					0,086	1,6
54					0,087	1,6
54,5					0,089	1,7
55					0,090	1,7
55,5					0,092	1,7
56					0,093	1,7
56,5					0,095	1,7
57					0,097	1,7
57,5					0,099	1,8
58					0,100	1,8
58,5					0,102	1,8
59					0,103	1,8
59,5					0,105	1,8
60					0,106	1,8
60,5					0,108	1,8
61					0,111	1,9

S4, S5 water temperature 10 °C FIBER BASALT CLIMA, all plastic pipe PP-RCT						
k=0,01	160 × 14,6		200 × 18,2		250 × 22,7	
Q 1/s	R kPa/m	v m/s	R kPa/m	v m/s	R kPa/m	v m/s
61,5					0,112	1,9
62					0,114	1,9
62,5					0,115	1,9
63					0,117	1,9
63,5					0,118	1,9
64					0,121	2
64,5					0,122	2
65					0,124	2
65,5					0,125	2
66					0,128	2
66,5					0,129	2
67					0,131	2
67,5					0,133	2,1
68					0,135	2,1
68,5					0,136	2,1
69					0,139	2,1
69,5					0,140	2,1
70					0,142	2,1
70,5					0,144	2,1
71					0,146	2,2
71,5					0,147	2,2
72					0,150	2,2
72,5					0,153	2,2
73					0,154	2,2
73,5					0,156	2,2
74					0,158	2,3
74,5					0,160	2,3
75					0,162	2,3
75,5					0,164	2,3
76					0,166	2,3
76,5					0,168	2,3
77					0,170	2,3
77,5					0,173	2,4
78					0,174	2,4
78,5					0,177	2,4
79					0,178	2,4
79,5					0,181	2,4
80					0,182	2,4
80,5					0,185	2,5

Operating parameters of PP-RCT piping systems

Tempera-ture [°C]	Time in operation [years]	Material PP-RCT S 5
		Maximum allowable pressure [bar]
10	1	19,0
	5	18,4
	10	18,2
	25	17,9
	50	17,7
20	1	16,6
	5	16,0
	10	15,8
	25	15,5
	50	15,3
30	1	14,3
	5	13,9
	10	13,6
	25	13,4
	50	13,2
40	1	12,3
	5	11,9
	10	11,7
	25	11,5
	50	11,3
50	1	10,5
	5	10,1
	10	10,0
	25	9,7
	50	9,6
60	1	8,9
	5	8,6
	10	8,4
	25	8,2
	50	8,1
70	1	7,5
	5	7,2
	10	7,0
	25	6,9
	50	6,8
80	1	6,2
	5	6,0
	10	5,9
	25	5,7
	1	4,7
95	5	4,4

Safety factor 1,5

CERTIFICATE

CQS has issued an IQNet recognized certificate that the organization:

WAVIN Ekoplastik s.r.o.

Rudeč 848, 277 13 Kostelec nad Labem okres Mělník, Czech Republic
Headquarters: Rudeč 848, 277 13 Kostelec nad Labem
Manufacturing and logistic centre: Dr. Černá 12/2659, hala K3, 193 00 Praha 9 - Horní Počernice
Distribution depots: Hradec Králové 59/4700, 586 03 Jihlava

has implemented and maintains a

Quality Management System

for the following scope

- Development, manufacture and sale of pipes and accessories
- Manufacturing and logistic centre
- Manufacturing and sale of pipes and accessories
- Distribution depots
- Sale of piping systems and accessories

which fulfills the requirements of the following standard:

ISO 9001:2015

Issued on: 2018 - 07 - 02

Expires on: 2020 - 07 - 15

This certification is directly linked to the IQNet Partner's original certificate and shall not be used as a stand-alone document.

Registration Number: CZ - 2098/2017

Alex Stočíkovič
President of IQNet

Tomas Hruška
President of CQS

CERTIFICATE
IQNet Partners:
ADMIRAL Spain, AFNOR Certification France, ALCATEL Portugal, CQC China, CIRQ Italy,
CQC China, COM China, COS Czech Republic, CSCC Germany, FCAS Brazil,
FONDODRUMA Venezuela, GOST-R Russia, IATF Colombia, INQS Holding, ISQI Germany, ITFCO Costa Rica,
IBAM Argentina, KATIAKARO Japan, KOREAN Quality Association, KOREAN Measurement AS Korea, LBNI Vietnam,
NKT-TESTING Mexico, NKTG Federal Quality Austria, QAS ER Russia, SII Israel, SISI Slovenia,
SIRIM QAS International Malaysia, SGS Switzerland, TÜV Nord Germany, TÜV Rheinland Germany, YUQS Serbia,
YUQS Turkey. IQNet is represented in the USA by AFNOR Certification, CIRQ, FCAS Holding, COSI and NSAI Inc.

* The fact of IQNet partners is valid at the time of issue of this certificate. Updated information is available under www.iqnet-certifications.com

CERTIFICATE

CQS has issued an IQNet recognized certificate that the organization:

WAVIN Ekoplastik s.r.o.

Rudeč 848, 277 13 Kostelec nad Labem okres Mělník, Czech Republic
Headquarters: Rudeč 848, 277 13 Kostelec nad Labem
Manufacturing and logistic centre: Dr. Černá 12/2659, hala K3, 193 00 Praha 9 - Horní Počernice
Distribution depots: Hradec Králové 59/4700, 586 03 Jihlava

has implemented and maintains a

Environmental Management System

for the following scope

- Development, manufacture and sale of pipes and accessories
- Manufacturing and logistic centre
- Manufacture and sale of pipes and accessories
- Distribution depots
- Sale of piping systems and accessories

which fulfills the requirements of the following standard:

ISO 14001:2015

Issued on: 2018 - 07 - 02

Expires on: 2020 - 07 - 15

This certification is directly linked to the IQNet Partner's original certificate and shall not be used as a stand-alone document.

Registration Number: CZ - 123/2017

Alex Stočíkovič
President of IQNet

Tomas Hruška
President of CQS

CERTIFICATE
IQNet Partners:
ADMIRAL Spain, AFNOR Certification France, ALCATEL Portugal, CQC China, CIRQ Italy,
CQC China, COM China, COS Czech Republic, CSCC Germany, FCAS Brazil,
FONDODRUMA Venezuela, GOST-R Russia, IATF Colombia, INQS Holding, ISQI Germany, ITFCO Costa Rica,
IBAM Argentina, KATIAKARO Japan, KOREAN Quality Association, KOREAN Measurement AS Korea, LBNI Vietnam,
NKT-TESTING Mexico, NKTG Federal Quality Austria, QAS ER Russia, SII Israel, SISI Slovenia,
SIRIM QAS International Malaysia, SGS Switzerland, TÜV Nord Germany, TÜV Rheinland Germany, YUQS Serbia,
YUQS Turkey. IQNet is represented in the USA by AFNOR Certification, CIRQ, FCAS Holding, COSI and NSAI Inc.

* The fact of IQNet partners is valid at the time of issue of this certificate. Updated information is available under www.iqnet-certifications.com

Discover our broad portfolio at wavin.com

Water management

Heating and cooling

Water and gas distribution

Waste water drainage



Wavin is part of Orbis, a community of companies working together to tackle some of the world's most complex challenges. We are bound by a common purpose: To Advance Life Around the World.

wavin

WAVIN Czechia, s.r.o. | Rudeč 848 | 277 13 Kostelec nad Labem | Czech Republic | Phone +420/ 326 983 111 | Fax +420/ 326 983 110 | www.wavinekoplastik.com | E-mail ekoplastik@wavin.com

Wavin operates a programme of continuous product development, and therefore reserves the right to modify or amend the specification of their products without notice. All information in this publication is given in good faith, and believed to be correct at the time of going to press. However, no responsibility can be accepted for any errors, omissions or incorrect assumptions.

© 2019 Wavin Wavin reserves the right to make alterations without prior notice. Due to continuous product development, changes in technical specifications may change. Installation must comply with the installation instructions.